## RYOBI 3200 S1 THEAD

## Frequently Used Part Numbers

Rollers

X07-0153 Form Roller, Soft

X07-0361 Pan Roller, Soft

X07-0455 Oscillator Roller, Hard

XSA-07009 Metering Roller Assy., Hard

(Roller, shaft, bearings, sleeves)

XSA-07008 Intermediate Roller Assy.

XSA-07007 Rider Roller Assy., Soft

Side Frame Assemblies

XSA-010190 OPS Side Frame Assy.

(Side frame w/ bearing & roll pin)

XSA-010191 NOPS Side Frame Assy.

(Side frame w/ bearing & roll pin)

Gears

XSA-03012 Pan Gear Assy.

(Gear w/ clutch bearing)

XSA-03013 Idler Gear Assy.

(Gear, bushing & shoulder bolt)

(2 per unit)

XSA-012 24 Tooth Drive Gear

XSA-03014 22 Tooth Idler Gear Assy.

(Gear, bushing, & shoulder bolt)

Side Frame Bearings

X06-107 Sealed Ball Bearing

Miscellaneous

XSA-1154 Water Pan Assy.

(w/ bottle bracket & pan bolts)

X99-123 Water Pan Bolt

X09-0206 Compression Spring Side Frame

X18-0710 Safety Cover

X99-28 Water Hose

X99-61 Wash Up Bottle

X88-125 Installation Manual

PRINTERS PARTS 800-543-1117 201-935-9595 fax 800-392-4072 201-935-5333 www.ppsnj.com

Adjustments

Roller Description

4/23/00 7