


INDEX

AI	Base
A2,A3	Covers
A4	Guards
A5	Collecting Tray
A6,A7	Vacuum Pump and Motors
B1	Air and Vacuum Pipes
B2,63	Drive Motor
B4	Feeder Side Frames
B5,B6,137,C1,	Feeder Mechanism
C2,C3,C4	
05,C6	Feeder Mounting Block and 4 Sucker System
07 -	Printer Side Frames
DI ,D2,D3,D4	Printer Link L.H. Side
D5,D6,D7	Printer
E1,E2	Impre- -n Cylinder
E3	Pre -n Mechanism
E4	Blan,
E5,E6,E7	Blanket Cledii,...,
F1 ,F2	Blanket Cleaning
F3,F4	Plate Cylinder
F5	Delivery Jogger and Roller Assembly
F6	Delivery Cylinder
F7,G1	Top Conveyor
G2,G3	Conveyor
G4,G5,G6,H1	Water Unit
H2,H3,H4,I-15,	Inker
H6,H7	
J3	Control Panel
J5	Light and Junction Box
J7	Wiring Harness
K1	Special Accessories
K4,K5	Magazine Feed
K6	Air and Vacuum Pipes with Blow Dry
K7	Tools
L1 ,L2,L3	Improved Air and Vacuum System
L4,L5,L6,L7	Feeder and Conveyor - Improved Registration
M1 ,M2,M3,	List of Changes from last issue
M4,M5	



Index No.	Pa7i Ni	Equal to	Part	Serial Ni
• 1	E14N153		Cover	
• 2	E14S065		Base -complete	
• 3	E14N156		Cover	
4	F14A001		Foot	
5	F14A002		Strain Relief	
6	F14A003	238	Collecting-Tray Support	
7	F14A004	88	Guide Bracket for Lower Cover -	

* 313 Parts

50	LOOR007	(25)	0R7	Washer	
51	LOOR020	(10)	0R20	Spring Washer	
55	LOHS231	(5)	16231	Screw	M4 x 16mm
56	L00S077	(10)	0S77	Screw	10-24 UNC x 1/4in long
57	L00S267	(5)	0S267	Screw	
58	P14S057	(5)		Stud	
59	L005379	(10)	C5379	Screw	8-32 UNC x 5/16in long
64	LOHT052	(10)	H152	Nut	10-24 UNC
65	LOOT002	(25)	012	Nut	5/16in - 18 UNC
70	L05E288	(5)		Air Pressure Label	
71	L05E289	(5)		Vacuum Label	
72	105E323	(5)		Air and Vacuum Label (French)	
73	L05E402	(5)		Approval Label (French)	
74	M14W007	(5)	3029W1	Label 10r3	
75	P14S103	(5)		Plug for 2	

70

71

72

73

17






74




75

2


AI



Index No.	Part No.	Equal to	Part	Ser	o.
1	E14N148		Printer Cover Upper R.H.		
2	E14N305		Printer Cover Upper Fl.11 (External Water Bottle M/C's)		
3	E14N096		Printer Cover Upper L.H. - complete with 9		
5	E14N172		Printer Cover Lower R.N.		
6	E14N093		Printer Cover Lower R.H. - complete with 95		
7	E14N057		Control Panel Cover		
8	E14N200		Feeder Cover L.H. - complete with 15		
9	F14A006	AU028	Door Magnet for 8		
10	E05E312		Name Plate 313 for 8		
11	F14A007	A13P	Locking Insert for 100		
12	E14R175		Bracket for 11 and 13		
13	E14R154		Bracket for 14		
14	F14A008		Microswitch for 1,3 and 6		
15	E14N140		Door for 8		
16	F14A011		Microswitch for 15		
17	E14N146		Bracket for 16		
18	F14J007		Microswitch for 3		
19	E14N248		Printer Cover Lower - R.H. (Rec.B/Wash Mica)		
20	E14N250		Printer Cover Lower - R.H. (Rec.BNVash and CPD Mica)		




Index No.	Part No.	Equal to	Part	ii No.
50	M14N001	(25)	Spring Clip for 99	
55	LOCR145	(25)	CR145	Lock Washer for 85
56	LOOR015	(10)	OR15	Washer for 85
57	L0LR022	(10)	LR22	Washer for 70
58	LOCR134	(25)	CR134	Spring Washer for 69
59	L02A025	(25)		Washer for 83
60	LOHW122	(4)	HW122	Spring Washer for 90
61	L0LF1008	(25)	LR8	Washer for 84
62	L02A075	(25)	802A075K99	Washer for 76
63	L00R025	(10)	01125	Washer for 73
67	M14A002	(5)		Screw for 97 1/4in -20 UNC x 1in long
68	L00S034	(10)	OS34	Screw for 98 & 99 1/4in - 20 UNC x 3/4in long
69	L00S036	(10)	OS36	Screw for 98 1/4in -20 UNC x 1in long
70	LOOS004	(25)	OST	Screw for 5 & 12 8-32 UNC x 1/2in long
71	LOOS115	(10)	OS115	Screw for 9 & 156-32 UNC x 3/8Th long
72	M14A007	(10)		Screw for 7 10-24 UNC x 1/2in long
73	LOOS015	(25)	OS15	Screw for 8 10-24 UNC x 1/2in long
74	M14A010	(10)		Screw for 8 10-24 UNC x 1in long
75	LOCS407	(10)	C5407	Screw for 104 8-32 UNC x 3/8in long
76	LOOS020	(10)	OS20	Screw for 7 1-24 UNC x 1.1/2in long
77	LOOS120	(10)	OS120	Screw for 17 10-24 UNC x 3/8in long
78	M14A003	(5)		Screw for 16 4-40 UNC x 3/4in long
79	M14A008	(10)		Screw for 15 6-32 UNC x 3/8in long
83	LODT001	(25)	DTI	Nut for 7 16-32 UNC
84	LOCT072	(25)	C172	Nut for 13 & 78 4-40 UNC
85	LOOT030	(10)	O130	Nut for 79 6-32 UNC
90	LOHU004	(4)	HU4	Spring for 101
95	LOOW050	(10)	OW50	Position Indicator for 3,4 and 6
96	P14N204	(10)		Latch for 1,3,5 and 6
97	P14N098	(3)		Stud for 1 and 3
98	LOOW111	(3)	OW111	Stud for 1,3 and 6
99	P10E010	(3)	910E010F99	Stud for 5
100	LOLW017	(4)	LW17	Lock Stud for 1,3 and 6
101	LOHW117	(4)	HW117	Lock Cap for 100
102	L02J136	(10)		Spacer for 14
103	P14N072	(10)		Spacer for 72 and 76
104	P14N145	(5)		Door Switch Arm for 15
105	L0CW877	(4)	CW877	Spacer for 72
106	L02J140	(5)		Spacer for 76
107	LOS E322	(5)		Speed Adjustment Label (French)
108	L05E321	(5)		Water and Ink Lever Label (French)
109	L05E320	(5)		Feeder Label (French)



Index No.	Part No	Equal to	Part	Serial No.
1	E05E292	10-3	Scale for 10	
2	E05E293	2D-3	Scale for 11 - R.H.	
3	E05E295		Scale for 11 - L.H.	
4	F14D301	30.3	Jogger Shaft	
5	F140002	170	Stud	
6	F140003	20D	Jogger Block	
7	F14D004		Shaft	
8	F140005	270	Link	
9	F140006	41J	Link	
10	E14G028		Collecting Tray	
11	E14G024		Back Guide - complete with 2 arid 3	
12	E14G017		Paper Guide - R.H.	
13	E14G044		Paper Guide - L.H. - assembled complete with 61,66,76 and 87	
14	F14R307	3R3	Paper Bail	
15	F14R308	8R-3	Spindle	


313 Parts

51	LOOP003	(25)	OP3	Spring Clip
52	LOOP002	(25)	OP2	Spring Clip
53	LOOP005	(25)	OP5,LP5	Spring Clip
56	LOOR003	(25)	OR3	Washer
58	LOOR005	(10)	ORS	Washer
59	10011042	(10)	01142	Plug
60	LOCR003	(25)	CR3	Lock Washer
61	LOOR061	(10)	01161	Lock Washer
66	L005075	(10)	OS75	Screw 5-40 UNC x 5/16in
67	M14J009	(25)		Screw Tufbk 8-32 UNC x 3/81n
88	L00S198	(10)	05198	Pivot Screw
69	L00S199	(5)	OS199	Locking Screw
70	L00S276	(5)	05276	Bolt M6 x 20mm
71	L00S036	(10)	0536	Screw 1/4in-20 UNC x lin long
75	LOHT050	(10)	HT50	Nut 1/4in 20 UNC
76	LOOT013	(10)	OT13	Nut 5-40 UNC
77	M14M009	(10)		Nut 10-32 UNF
82	M140002	(5)	70-3	Spring
87	L00W058	(5)	OW58	Support Pad
88	L00W059	(3)	OW59	Stud
89	M140001	(5)		Wing Nut
90	LOOW060	(3)	OW60	Pin




Index No.	Part No.	Equal to	Part	Serial No.
1	F14C001	103C	Base Board	
2	E141006	9141006L99	Vacuum Pump .750in (19.06mm) dia. Shaft old-style	
3	F14C002	95C	Adaptor	
4	E141007	9141007G99	Pulley for 2 .7501n (19.06mm dia. Bore	
• 5	F14E012	4E-3	Motor 1/2h.p. 100V/110V 50 Hz	
• 6	F14E013	6E-3	Motor 1/2h.p. 200V/220V 60 Hz	
• 7	F14E014	9E-3	Motor 1/2h.p. 220V/240V 50 Hz	
* 8	F14E015	10E-3	Motor 1/2h.p. 100V 50Hz/50 Hz	
• 9	E141043		Pulley 50 Hz	
• 10	E141044		Pulley 60 Hz	
• 12	F14C010	6C	.V* Belt (Motor to Pump) - 50 Hz	
• 13	F14C304	7C	V Bell (Motor to Pump) - 60 Hz	
15	F14C013		Clamp	
16	E141065		Filter Assembly with 24 and 91	
17	F14C014	96C	Element	
18	E14T010	9141010G99	Sealing Washer	
19	E14T011	9141011C99	Stud	
20	F14C015	16C	Coupling	
21	F14C016	17C	Adaptor	
22	E141014		Bracket	
23	E141070		Air Valve Assembly	
24	F14C032		Adaptor	
25	E141056		Vacuum Valve Assembly	
26	E141051		Vacuum Tee	
27	F14C021	101C	Connector	
29	F14C025	102C	Air Hose 533mm (21in) long	
30	F14C024	84C	Cover	
31	F14E021	122W	Gland	
32	E14R214		Lead for 5, 6, 7 and 37	
33	E14R215		Lead for 8 and 34	
34	F14E023	5E-3	Motor 1/2h.p. 110/120V 60 Hz (CSA)	
35	F14E026		Plug for 32 and 33	
36	E14R259		Thermal Cut-out Harness for 34 (CSA&UL)	
37	F14E029		Motor 1/2h.p. Dual Voltage 50 Hz	
39	E14T001		Vacuum Pump with 40 .7871n (20mm) dia Shaft	
40	E141071		Pulley for 39 .7871n (20mm) dia. Bore	

* 313 Parts




Index No.	Part No.	Equal to	Part	Serial No.
50	LOOR003 (25)	0133	Washer	
51	LOOR007 (25)	0R7	Washer	
52	L00R066	(25) 0R66	Lock Washer	
53	P14T012	(10) 9141012Y99	Washer	
54	LOCR005 (25)	CR5	Lock Washer	
57	LOHS175	(10) HS175	Screw	144in-28 UNF x 3/4in long
58	LOCS410	(10) CS410	Screw	1/4in-20 UNC x 3/8in long
59	L00S033 -	(25) OS33	Screw	1/4in-20 UNC x 5/8in long
60	L00S166	(25) OS166	Screw	10-32 UNF x 1/4in long
61	L00S257	(5) OS257	Bolt	M8 x M25
62	M14C001	(5) 222765173P	Bolt	M8 x M40
66	M14G006	(10) LOHT055	Nut	1/4in-28 UNF
67	LOOT006	(5) OT6	Nut	5/8in - 18 UNF
69	LOHT006	(10) OT37,HT6	Nut	M8
69	P14T009	(10) 914TOMY99	Nut	2 BA
74	L00U093	(5) OU93	Spring	
79	LOOW021	(2) OW21	Knob	
80	L00W055	(5) OW55	Wing Nut	1/4 - 20 UNC
81	L00W197	(5) OW197	Collar	
82	L02J129	(5)	Spacer	
83	LOHW104	(10) HW104	Tie tor 36	
84	M14W037	(10)	Eyelet for 32,33 and 36	
85	M14W017	(10)	Terminal for 36	
86	M14W020	(10)	Tab for 36	
87	M13V006	(10)	Boot for 86	
88	LOG W495	(25) CW495	Boot for 85	
89	LOHW410	(5) HW410	Clip	
90	LOHWO93	(10) HW93	Tie Retainer for 2 - (not shown)	
91	P141086	()	Tube	







Index part No.	Equal to	Part	Serial
1* F14E301	1E-3	Speed Adjuster Shaft	
2 F14E002	701E	Arm	
3 F14E024		Adjusting Rod	
4 F14E025		Adjusting stud	
5 F14E003	26E	'V' Belt (Clutch to Motor)	
6 F14E004	79E	'V' Belt (Clutch to Drive Shaft)	
		- 50 Hz	
7 F14E005	27E	'V' Belt (Clutch to Drive Shaft)	
		- 60 Hz	
8 F14E006	30E	Bearing Plate - front	
9 F14E007	33E	Shaft	
10 F14E008	35E	Pulley - small	
11 F14E009		Shoe	
12 F14E010	38E	Pulley - large	
13 F14E011	41E ----	Bearing Plate - back	
14 F14E012	4E-3	Drive Motor 1/2 hp 100v/110v 50 Hz	
15 F14E023		Drive Motor 1/2 hp 110v/120v 60 Hz (CSA)	
16 F14E013	6E-3	Drive Motor 1/2 hp 200v/220v 60 Hz	
17 F14E014	9E-3	Drive Motor 1/2 hp 220v/240v 50 Hz	
18 F14E015	10E-3	Drive Motor 1/2 hp 100v 50 Hz/60 Hz	
19 F14E016	64E	Inner Pulley	
20 F14E017	65E	Outer Pulley	
21 F14E018	17E	Spring	
22 E14J062	66E	Key	
23 E14J082		Lever	
24 E14I033	70E	Shaft	
25 E14L029		Handle	
26 E14I025		Speed Indicator Dial	
27 F14E020		Gland for 14,16,17 and 18	
28 F14E021	122w	Gland for 15	
29 E14R212		Lead for 14,16,17 and 18	
30 E14R213		Lead for 15	
31 F14E026		Plug for 29 and 30	
32 E14R260		Thermal Cut-out Harness for 15 (CSA/UL)	


* 313 Part



Index No.	Part No.	Equal to	Part	Serial
50	L00P002	OP2	Spring Clip	
51	LOOP021	(25) OP21	Spring Ct.:2	
59	LOOR002	(25) OR2	Washer	
60	LOOR007	(25) OR7	Washer	
61	LOOR080	(10) OR80	Spring Washer	
62	LOOR006	(10) OR6	Washer	
70	L00S033	(25) OS33	Screw 1/4 in-20 UNC x 5/8 in	
71	L00S047	(2) OS47	Screw 3/8 in-16 UNC x 3.1/4 in	
72	L00S060	(5) OS60	Screw 5/16 in-18 UNC x 3/4 in	
73	L00S046	(5) OS46	Screw 3/8 in-16 UNC x 1 in	
74	L00S167	(25) OS167	Screw 10-32 UNF x 5/16 in	
75	L00S170	(10) OS170	Screw 1/4 in-20 UNC x 1/4 in	
81	LOOT002	(25) O72	Nut 5/16 in-18 UNC	
82	M14E001	(10) 217811946P	Nut 5/8 in-18 UNF	
89	L00U003	(5) OU3	Spring	
90	L00U094	(5) OU94	Spring	
95	L00W022	(2) OW22	Bearing	
96	L00W046	(25) OW46	Spring Dowel 5/32 in dia. x 1 in	
98	L00W061	(5) OW061	Expansion Plug	
99	L00W062	(20) OW062	Key	
100	L00W066	(3) OW66	Thrust Washer	
101	M14E003	(5)	Pad	
102	M14E002	(25) 211285127P	Split Pin 3.2mm x 20mm	
103	LOHW104	(10) HW104	Tie	
104	M14W037	(10)	Eyelet for 29,30 and 32	
105	M14W017	(10)	Terminal for 32	
106	M14W020	(10)	Tab for 32	
107	M131/006	(10)	Boot for 106	
108	LOCW495	(25) CW495	Boot for 105	




Index No.	Part No.	Equal to	Part	Serial
1	F14F001	1F	Cam	
2	F14F002	4F	Feedboard Chain Guard - R.H.	
3	F14F003	3F	Feedboard Chain Guard - L.H.	
4	E14F003		Feedboard Runner	
5	F14F004	17F	Adjusting Screw for 4	
6	E14E179		Feeder Side Frame - L.H.	
7	E14E178		Feeder Side Frame - R.N.	
57	LOOR003	(25) OR3	Washer for 76	
58	LOOR007	(25) OR7	Washer for 75	
65	LOOS014	(25) OS14	Screw for 2	10-24 UNC x 3/8 in and 3
66	LOOS018	(25) OS18	Screw for 1	10-24 UNC x 7/8 in
67	LOOS037	(10) OS37	Screw for 5	1/4 in-20 UNC x 1.1/4 in
68	LOOS054	(5) 0554	Screw for 82	5/16 in-18 UNC x 1.1/4 in
69	100S073	(10) 0573	Screw for 4	10-24 UNC x 1/2 in
75	LOOT003	(25) OT3	Nut for 68	5/16 in-18 UNC
76	LOHT050	(10) HT50,OT9	Nut for 67	1/4 in-20 UNC
82	LOOU007	(5) 007	Cushion Spring for 6 and 7	
90	LOOW068	(5) 0868	Spring Peg for 6	
91	LOCW562	(10) 0842,CW562	Spring Dowel for 6	1/8 in x 3/4 in
97	1008075	(3) 0W75	Spring Peg for 6	
98	LOOW076	(3) 0W76	Spring Peg for 6	
99	LOOW207	(4) 0W207	Bush for 6 and 7	
100	LOOW208	(5) 0W208	Bush for 6	
101	LOOW070	(3) 0W70	Spring Pin for 6	
102	LOOW071	(5) 0W71	Pin for 6	
103	LOOW218	(5) 0W218	Spring Peg for 7	
104	LOOW074	(3) 0W74	Spring Peg for 7	




Index No.	Part No.	Equal to	Part	Serial
1*	E14E112	14G-3	Deflector	
2	F14G002	2G	Stud	
3	F14G003	46	Stud	
4	F14G004	5G	Arm	
5	F14G005	65H	Arm	
6	F14G006	66H	Shaft	
7	F14G007	6CH	Stop	
8	E14G022		Link	
9	E14R196		Solenoid	
10	E14G023		Bracket	
11*	F14G301	1G-3	Second Feed Roller	
12	F14G010	96	Gear	
13	E14E135		Shaft	
14	E14E050	3046	Arm	
15	F14G014	206 --	Sucker - R.H.	
16	F14G015	21G	Sucker - L.H.	
17*	E14E143		Removable Holder	
19*	E14E158		Screw	
20	E14E206		First Feed Roller	
21	F14G018	33G	Gear	From 16[
22	F14G019	94G	Intermediate Gear	
23	F14G020	956	Stud	
24	F14G021	366	Back Plate	
25	F14G022	37G	Spring	
26	F14G023	436	Front Paper Guide	
27	F14G024	446	Paper Separator Blower (centre)	
28	E14E160	305G	Arm - L.H.	
29	E14E029	2006	Arm - R.H.	
30	E14E131	2016	Sucker Arm	
31	F14G028	266	Adjusting Block (fitted to 30)	
33	E14E200	106-3	Spindle	
34*	E14E054		Sucker Spindle - complete with 28, 29 and 30	
35	F14G201	96-2	Gear	
36*	E14E062		Cam	
37	F14G032	2756	Spacer	
38*	E14E027	126-3	Height Control Cam	
39	E14E022	76-2	Sucker Cam	
40*	E14E066		Camshaft - complete with 35,38,39 and 96	
41*	E14E130	2296	Sucker (packed in a carton)	
42	E14E211		Paper Separator Blower (centre) New-style, See L1	From 16D

* 313 Parts


Note: For 4 Sucker System see C5



Index No.	Part No.	Equal to	Part	Serial
52	LOCP013 (2)	CP3	Spring Clip	
53	LOCP009 (10)	CP9	Spring Clip	
57	LOCR153 (10)	CR153,0R21	Washer	
58	LOCR108 (10)	CR108	Washer	
59	LOOR007 (25)	OR7	Washer	
60	LOOR008 (10)	OR8	Washer	
66	LOOS002 (25)	OS2	Screw	8-32 UNC x 1/4 in
67	LOOS004 (25)	OS4	Screw	8-32 UNC x 1/2 in
68	LOOS009 (25)	OS9	Screw	10-32 UNF x 1/2 in
69	M14G002 (25)	OS16	Screw	10-24 UNC x 5/8 in
70	LOOS018 (25)	OS18	Screw	10-24 UNC x 7/8 in
71	LOOS008 (25)	OS8	Screw	10-32 UNF x 3/8 in
72	LOOS074 (10)	OS74	Screw	8-32 UNC a 1/2 in
73	LOOS156 (10)	OS156	Screw	10-24 UNC x 5/16 in
74	LOOS252 (10)	OS252	Screw	1/4 in-20 UNC x 5/16 in
75	LOCS419 (25)	CS419	Screw	6-32 UNC x 1/4 in
76	LOOS005 (10)	OS5	Screw	8-32 UNC x 3/4 in
81	LOOT010 (5)	O110	Nut	5/16 in - 18 UNC
82	LOOT030 (10)	O730	Nut	6-32 UNC
87	LOCU256 (5)	CU256	Spring	
88	100U009 (10)	O09	Spring	
89	L000010 (25)	Ou10	Spring	
90	L000089 (5)	O089	Spring	
95	M140005 (25)		Taper Pin HT	3/16 in x 7/8 in
96	M140002 (25)		Taper Pin HT	3/16 in x 1 in
97	LOCW562 (10)	OW42,CW562	Spring Dowel	1/8 in dia. x 3/4 in
98	P14E157 (5)		Pin	
99	LOOW079 (10)	OW79	Leaf Spring	
101	LOOW210 (25)	OW210	Plunger	
102	L03S211 (5)		Peg	
103	LOCW766 (10)	CW766,OW8	Taper Pin	5/32 in x 7/8 in




Index No.	Part No.	Equal to	Part	Serial t
50	L00P005 (25)	OP5	Spring clip for 1s	
51	LOCP008 (25)	CP8	Spring clip for 8	
56	LOOR001 (25)	OR1	Washer for 67	
57	LOOR003 (25)	OR3	Washer for 68 and 70	
58	LOOR004 (10)	OR4	Washer for 80	
59	LOOR007 (25)	OR7	Washer for 78	
60	LOOR011 (10)	OR11	Washer for 80	
61	LOOR012 (5)	OR12	Washer for 80	
62	LOOR0211 (10)	OR20	Spring washer for 67	
63	LOCR005 (25)	CR5	Lock washer for 81	
67	L00S020 (10)	OS20	Screw for 25 10-24 UNC x 1.1/2 in	
68	L00S036 (10)	OS36	Screw for 8 1/4 in-20 UNC x 1 in	
69	L00S043 (25)	OS43	Screw for 21 8-36 UNF x 1/2 in	
70	100S048 (5)	OS48	Locking Screw for 23	
71	L00S158 (10)	OST516	Screw for 86 10-24 UNC x 3/4 in	
72	100S355 (10)	CS355,05196	Screw for 6 1/4 in-20 UNC x 3/4 in	
73	L00S348 (10)	CS348	Screw for 27 8-36 UNF x 3/8 in	
78	1001002 (25)	O72	Nut for 14 5/16 in-18 UNC	
79	LOHT050 (10)	HT50,079	Nut for 3 1/4 in-20 UNC and 72	
80	LOOT017 (10)	O717	Nut for 12, 3/8 in-16 UNC 15 and 16	
81	M14G005 (10)	218811031P	Nut for 72 1/4 - 20 UNC	
86	L00U013 (10)	0013	Spring for 24	
87	1000014 (10)	0014	Spring for 11	
88	1000015 (10)	0015	Spring for 19	
89	1000017 (25)	0017	Spring for 13	
94	10CW765 (25)	CW765	Taper Pin for 173/16 in x 1.1/4 in	
95	L000007 (25)	OW7	Taper Pin for 183/16 in x 1 in	



16




Index No.	Part No.	Equal to	Part	Serial
1	F146091	1076	Swivel Bracket	
2	F14G092	1246	Screw	
3*	F146313	226-3	Lifting Shaft	
4	F146094	1226	Blower - R.N.	
5	F146095	1196	Bracket - R.H. - not for Magazine Feed	
6	F146096	1326	Blower - L.H. -	
7	F146097	1286	Bracket - L.H. - not for Magazine Feed	
8	F146098	133G	Back weight	
9*	F146314	23G-3	Shaft	
10	F14G100	2256	Side Arm - L.H. - complete with 60 and??	
11	F14G101	226G	Side Arm - R.H. - complete with 60 and??	
12	F14G102	3096	Side Fence	
13	E14F034		Feedboard Guide - L.H. and R.H.	
14	E14F053		Bracket - L.H. (not shown)	
15	E14F052		Bracket - R.N.	
16	E14F035		Support	
17	F146125	1516	Feed Guide - L.H.	
18	F146126	1526	Feed Guide - R.H.	
19	See 87-9			
* 313 Parts				
50	LOCPO08 (25)	CP8	Spring Clip	
56	M146002 (25)	OS16	Screw	10-24 UNC x 5/8 in
57	M14J007 (10)		Screw	10-32 UNF x 7/16 in
59	LOOS017 (25)	OS17	Screw	10-24 UNC x 3/4 in
60	L005024 (25)	OS24	Screw	6-32 UNC x 1/2 in
61	M146007 (10)		Screw	8-32 UNC x 3/8 in
63	L005199 (5)	OS199	Screw	
64	L005255 (10)	OS255	Screw	
66	L005200 (5)	OS200	Screw	
68	LOOT010 (5)	07010	Nut	5/16 in-18 UNC
74	LOCW562 (10)	CW562	Spring Dowel	1/8 in dia. x 3/4 in
76	L00W080 (5)	OW80	Spring Plate	
77	L00W082 (5)	OW82	Eccentric Nut	
78	L004083 (10)	OW83	Plate	




Index No.	Part No.	Equal to	Part	Serial N
3	F14G127	155G	Feedboard Lifting Gear and Ratchet Wheel	
6	F14G128	165G	Stud	
7	E14E090	159G	Lifting Plate	
8	E02S016	161G	Roller	
10	E14E059		Brake	
11	F14G132	162G	Lifting Pawl	
12	F14G133	163G	Eccentric Screw	
13	E14E093	256G	Drive Arm - complete with 14, 52 and 62	
14	E02S018	215G	Roller	
15*	E14E102	24G-3	Height Control Bar	
16	F14G137	247G	Height Control Knob	
17	F14G138	252G	Stud	
18	F14G139	254G	Pin	
19	E14E048	255G	Operating Link	
20	F14G141	258G	Trip Pawl Link	
21	E14L021		Handwheel - complete with 22, 23, 65, 71 and 77	
22	E14L023		Handle	
23	E05E302		Label	
24	F14G143	2996	Connecting and Operating Arm - Assembly complete with 101	
25*	See K5,1		Height Control Bar for Magazine Feed	
26	E14E039		Arm	


* 313 Parts






Index No.	Part No.	Equal to	Part	Serial
50	LOOP002	(2	ip2	Spring Clip
51	LOOP003	(25)	OP3	Spring Clip
52	L01P005	(10)	LP5,OP5	Spring Clip
53	LOOP006	(25)	OP6	Spring Clip
55	LOOP011	(25)	OP11	Spring Clip
56	LOOP012	(25)	OP12	Spring Clip
61	LOCR043	(25)	CR043	Washer
63	LOOR013	(10)	OR13	Washer
64	LOOR014	(25)	OR14	Washer
65	P14L024	(10)		Cup Washer
71	L00S022	(10)	OS22	Screw
72	L00S168	(10)	OS168	Screw
73	L0CS386	(10)	CS386	Lock Screw
75	L00S201	(5)	OS201	Pivot Screw
76	L00S202	(3)	OS202	Screw
77	M14G001	(10)		Screw
83	LOOT018	(5)	OT18	Nut
84	10CT076	(5)	C176	Nut
85	M146006	(10)		Nut
90	L00U018	(25)	0018	Spring
91	L00U019	(10)	0019	spring
92	L00U020	(5)	0020	Spring
93	L00U021	(25)	0021	spring
94	L001J022	(5)	0022	Spring
100	LOCW035	(25)	CW35	Spring Dowel
101	M14J005	(25)		Taper Pin
103	L00W084	(3)	OW84	Eccentric Stud
104	L00W085	(10)	OW85	Plug
105	L00W020	(25)	OW20	Pin
106	LOCW562	(10)	OW42,CW562	Pin



Index No.	Part No.	Equal to	Part	Serial No.
1*	E14E152		Vacuum Manifold Shaft	
2	F14H002	211	Air Pipe Connector	
3	F14H003	3H	Coupling	
4	F14H004	56H	Vacuum Connecting Tube	
5*	E14E153		Inner Sucker Hose	268mm
			(Old-style not shown)	(10.1/2 in)
6*	F1411304	411-3	Bottom Shaft	
7	F14H007	10H	Roller Arm - R.H.	
8	F14H008	12H	Top Spindle	
9	F14009	1711	Roller	
10	F14H010	1911	Two Sheet Ejection Roller	
11	F14H011	20H	Roller Arm - L.H.	
13	F14H013	32H	Eccentric Arm	
14	F14H014	3411	Adjusting Spindle	
15	F14H015	45H	Latch	
16	F14H016	4311	Knob	
17	E14E067		Two Sheet Mounting Block - complete	
18	E14E060		Mounting Block only	
19	F14H018		Trigger Plate	
20	F14H019		Adjusting Plate	
21*	E14R204		Microswitch and Harness Assy.	
22	E14E061		Cover	
23	F14W027		Connector - 2 way	
24*	F1411301		Y-Hose Connector	
25*	E14E156		Distributor Sucker Hose	179mm
			(Old-style not shown)	(7 in)
4 SUCKER SYSTEM				
30*	E14E173		4 Sucker System - complete	From 1
			with 2, 24, 31-39, 65, 103	
31*	F14G014	20G	Sucker - L.H.	
32*	F14G015	21G	Sucker - R.H.	
33*	E14E143		Removable Holder	
34*	E14E158		Screw	
35*	E14E130	22%	Sucker	
36*	E14E154		First Outer Sucker Hose	
37*	E14E155		Second Outer Sucker Hose	
38*	E14E156		Distributor Sucker Hose	
39*	F14H305		Syphon Tap	1/4 in
* 313 Parts				



Index No.	Part No.	Equal to	Part	Serial No.
51	L00P006 (5)	OP6	Spring Clip	
52	LOOP011 (25)	OP11	Spring Clip	
57	LOCR139 (25)	CR139	Lock Washer	
58	LOOR001 (25)	OR1	Washer	
59	LOCR036 (25)	CR36	Washer	
60	L0LR022 (10)	LR22	Washer	
64	1005003 (25)	OS3	Screw	8-32 (INC x 3/8 in
65	L00S009 (25)	OS9	Screw	10r-32 UNF x 1/2 in
66	L00S061 (3)	OS61	Screw - L.H.	
67	L00S078 (5)	OS78	Screw	
68	L00S155 (10)	OS155	Screw	10-24 UNC x 3/16 in
69	1005177 (10)	OS177	Screw	8-32 (INC x 3/16 in
70	L00S185 (10)	OS185	Lock Screw	10-24 UNC x 1/8 in
71	M14H004 (5)		Screw	1/4 in-28 UNF x 3/8 in From
72	L00S205 (10)	OS205	Screw	
73	L00S028 (25)	06211	Screw	8 BA x 3/4 in
74	LOCS419 (25)	CS419	Screw	6-32 (INC x 1/4 in
79	M14H002 (25)		Nut	8 BA
84	L00U023 (10)	OU23	Spring	
85	L00U024 (10)	OU24	Spring	
86	L00U025 (10)	OU25	Spring	
91	L00W023 (25)	OW23	Pin	3/32 in dia. x 1/2 in
92	L00W085 (10)	OW85	Plug	
93	L00W086 (5)	OW86		
94	L00W087 (5)	OW87	Bottom Spindle	
95	L00W088 (5)	OW88	Spindle	
96	L00W089 (5)	OW89	Regulator Shaft	
97	P14E108 (5)	OW90	Guide	
98	L00W091 (5)	OW91	Lock Knob	
99	L00W092 (5)	OW92	Adjusting Collar	
100	M14H001 (10)		Clamp	
101	L00W193 (5)	OW193	Plate	
102	M14H003 (10)		Plug for 1 (old-style not shown)	
103	P14E157 (5)		Pin	



==4:1 aztr=O

VAKI

75 58 59 53 71 64 77

OD On liOLD M1=170 (19-11 art a- IME;:::1

78 79 80 81 82 84 86

czQ O E1
5 57 65 56&94

Wage 11 i C==U
60 7 62 8

CE;:::8 4:112) Em i

12 13 92 90,94 14

Fna 174D O

61 66 69 63 68 67 16 88 55 52&54

17 FZ 0 GEEII
70

18


74 51
21 73

22 53

Index No.	Part No.	Equal to	Part	serial N(
1	E14A103		Side Frame Sub Assembly R.H. complete as shc	
2	E14A082	14.1-2	Side Frame Sub Assembly L.H. complete as shown	
3*	F14J303	3J-3	Support for 1,2	
5	E14A129		Block for 2, See Index 2 D1	
6*	E14N196		Two Sheet Collecting Tray	
7	E14E037		Support for 6	
8	E14R198		Connector Bracket (Wiring Harness) for 1	
9	E10A454		Bracket for 2	
10	F14J006		Push Button for 9	
11	F14J007	281211250P	Microswitch for 10	
12*	F14J201	4J-2	Pivot Stud for 2, See Index 18 D1	
13*	F14J202	7J-2	Pivot Stud for 2, See Index 9,27 and 29 D3	
14	E14A127		Stop Block See Index 95 D7	
15	E14A130		Stop Block - Bottom See Index 16 E1	
16	E14A131		Stop Block - Top See Index 23 D1	
17*	F14J305	5J-3	Spacer Tube for 1	
18*	E14A104		Blanket Cylinder Guard Rod	
19*	F14J302	2J-3	Paper Deflector for 3	
20	F14L006	28-L	Molleton Roller Link L.H.	
21	F14N033	510C-S	Cylinder Position Microswitch	
22	E14R103		Bracket for 21	
50	LOCPO05	(25) CPS	Spring Clip for 7	
51	LOCRO07	(25) CR7	Washer for 74	
52	LOOR003	(25) OR3	Washer for 56	
53	LOOR007	(25) OR7	Washer for 71	
54	LOCRI53	(10) CR153	Washer for 55,62	
55	M14J007	(10)	Screw for 9	10-32 UNF x 7/16 in
56	L00S036	(10) OS33	Screw for 5,92	1/4 in-20 UNC x 1 in
57*	P14A139	(5)	Screw for 5	1/4 in-28 UNF x 1.1/4 in
58	L00S055	(3) OS55	Screw for 71	5/16 in-18 UNC x 2.3/4 in
59	L00S057	(3) OS57	Screw for 1,2,3	5/16 in-18 UNC x 1.1/4 in
60	M14J002	(10)	Locking Screw for 6	10-24 UNC x 1.1/4 in
61	L00S017	(25) OS17	Screw for 14,15,16	10-24 UNC x 3/4 in
62	L00S015	(25) OS15	Screw for 7	10-24 UNC x 1/2 in
63*	P14A140	(5)	Screw for 14,15,16	1/4 in-20 UNC x 1 in
64	L00T003	(10) 073	Nut for 71	5/16 in-18 UNC
65	M14G006	(10)	Nut for 57	1/4 in-28 UNF
66*	P14A141	(5)	Screw for 14	10-32 x 7/8 in
67	LOHT050	(10) HT50	Lock Nut for 63	1/4 in-20 UNC
68	L00T008	(25) 018	Nut for 63	1/4 in-20 UNC
69	L001023	(10) 0723	Nut for 66	10-32 UNF
70	M14F002	(10)	Screw for 18	3/8 in x 16 UNC x 1.1/4 in
71	L00U026	(3) OU26	Cushion Spring for 1,2,3	
73	L00S439	(10) CS439	Screw for 21	M3.5 x 30mm
74	L0LT004	(25) LT4	Nut for 73	M3.5
75	L004027	(10) OW27	Dowel Pin for 3	1/4 in dia. x 1.1/4 in
77	L004093	(4) OW93	Bush for 1,2	
78	L004094	(4) OW94	Bush for 1,2	
79	L00W095	(4) OW95	Bush for 1,2	
80	L004096	(10) OW96	Stud for 1,2	
81	L004097	(5) OW97	Spring Peg for 1	
82	L03W115	(5)	Spring Peg for 2	
84	L004104	(5) OW104	Spring Peg for 2	
85	L0C4823	(10) CW823	Spring Dowel for 2,6 3/16 in dia. x 1 in	
86	L004068	(5) OW63	Spring Peg for 1, See Index 87 D7	
88	M14J004	(5)	Spacer for 14	
90	L00S034	(10) OS34	Screw for 92	1/4 in-20 UNC x 3/4 in
92	L004111	(3) OW111	Cover Stud for 1	
93	L00S237	(10) OS237	Screw for 20	
94	M14J008	(10)	Screw Tuflok for 12,13,96	1/4-20 UNC x 3/4 in
96	L004106	(5) OW106	Stud for 2	
98	L034077	(5)	Peg for 2	


* 313 Parts

C7



Index No.	Part No.	Equal to	Part	SerialNo
2*	E14A133		Blanket Eccentric Rocker	
4	F14K004		Stud — Tuflok	
5	F14K005		Inker Shut—off Link — complete	
6	F14K006	11K	Spacer	
7	E14R153		Plate	
8	E14R154		Bracket	
9	E14R301		Counter Microswitch	
10	E14M004		Switch Link	
11	F1414008	31K	Blanket Eccentric Pivot Arm	
12	F14K009	33K	Roller	
13	E14A018	95Q	Cam	
14	E14A060		Feeler Secondary Link	
15	F14K012	36K	Stud	
16	F14K013	4C	Pivot Bracket	
17	F14K014	44K	Feeler Primary Link	
18*	F14K207	7K-2	Feeler Swing Arm	
19*	E14A074	23K-2	Blanket Cylinder Push Bar	
20	F14K017		Retaining Block	
21	F14K018	50C	Support Block	
22*	F14K302	2K-3	Impression Shut—off Lever	
23*	E14A205		Impression Shut—off Plate	
24*	F14K205	20K-2	Link	
26*	E140047		Link	
27	See Index 5—C7		Stop Block	


* 313 Parts



Index Part No.	Part N-	Equal to	Part	Serial No.
51	LOCP000	(25) CP6	Spring Clip	
52	LOLP005	(10) LP5,OP5	Spring Clip	
53	LOOP003	(25) OP3	Spring Clip	
54*	LOOP001	(25) OP1	Spring Clip	
55*	LOOP006	(25) OP6	Spring Clip	
56*	LOCR134	(25) CR134	Washer	
57	LOOR008	(10) OR8	Washer	
58	LOCR133	(10) CR153,OR21	Washer	
59	M141(001	(10)	Washer	
64	L00S178	(10) OS178	Screw	8-32 UNC x 3/16 in
65	M14G002	(25) OS016	Screw	10-24 UNC x 5/8 in
66	L00S018	(25) OS18	Screw	10-24 UNC x 7/8 in
67	P14A139	(5) OS52	Stop Screw	1/4 in-28 UNF x 1.1/4 in
68	L00S207	(10) 17S207	Screw	
69	L01E059	(10)	Screw	
70	L00S225	(5) OS225	Eccentric Screw	
71	P14A126	(5)	Stud	
72	LOCS366	(10) CS366	Screw	1/4 in-20 UNC x 3/4 in
73*	L00S228	(10) OS228	Stud - old-style (not shown)	
74*	P14A139	(5)	Stop Screw	1/4 in-28 UNF x 1.1/ 4 in
75	LOCS305	(25) C5305	Microswitch Operating Screw	1/4 in-28 UNF x 1/2 in
76	M14G006	(10)	Nut	
78	L00T023	(10) OT023	Nut	10-32 UNF
79	LOCT072	(25) CT72	Nut	4-40 UNC
80	LOCT076	(5) C176	Half Nut	1/4 in-28 UNF
81*	L00U080	(5) OU80	Spring	
84	L00U013	(10) OU013	Spring	
85	L00U028	(10) OU028	Spring	
86	L00U032	(10) OU032	Spring	
87	L00U033	(10) OU033	Spring	
90	L04A123	(10)	Spring	
94	L00W003	(25) OW3	Taper Pin	11/64 in x 7/8 in
95	L03W077	(5)	Spring Peg	
97	L00W113	(5) OW113	Pin	
98	E02J128	(5)	Spacer	
99	L00W099	(5) OW99	Spring Peg	
100*	L00W199	(5) OW199	Stud	
101	M14K003	(5)	Spacer	
103*	L004200	(10) OW200	Stud	
104	L01E055	(4)	Stud	Tuflok
105	L01E060	(3)	Pivot Screw	Tuflok
106	M141(006	(10)	Push-on Fix	
107	P14A177	(5)	Stud	
108	LOCP004	(25) CP4	Spring Clip	
109	M14J008	(10)	Screw Tuflok	1/4 in-20 UNC x 3/4 in
110	L00W107	(5) OW107	Stud	
111	L00W106	(5) OW106	Stud	


* 312/313 Parts

* 312/313 Parts




Index No.	Part No.	Equal to	Part	Serial 1
1*	F14L301	1L-3	Dampening and Ink Forme Roller Cam Shaft	
3	F14L003	70L	Sleeve	
4	F14L004	3L	Position Plate	
5	F14L005	16L	Link	
6	E14A016	18L	Link	
7	F14L006	28L	Molleton Roller Link - L.H.	
8	F14L007	29L	Molleton Roller Link - R.H.	
9	E14A096	2L-2	Arm - bottom	
10	E14A023	38L	Feeler Pawl	
12	F14L009	55L	Inker Water Link	
13	F14L010	65L	Water Ductor Link	
14	F14L011	66L	Eccentric Nut	
15	F14L012		Ink Ductor Link	
17	F14L013	69L	Yoke	
18	E14L028		Hub	
19	E14L034	73L	Lever	
20	E14L029		Handle	
21	E14J023		Plunger Bracket	
22	F14L014	77L	Plate Cylinder position Key	
23	F14L015	76L	Flange	
24	E14K001		Knob - complete with 66 and 99	
25	E14H115		Idle Gear	
26	E14A029	1L-2	Lever	
27	E14D012		Arm	
29	F14K203	12K-2	Cam Follower and Detector Arm - complete	
30	E14A063	82L	Safety Spring Lever	
31	E05J015		Eccentric	
32	F14J202	7J-2	Pivot Stud	

* 313 Parts



Index No.	Par NC		Equal to	Part	Serial No.
51	LOOP005	(25)	0P5	Spring Clip	
52	LOOP006	(25)	0P6	Spring Clip	
55	M14R004	(25)		Spring Clip	
56*	LOOP001	(25)	0P1	Spring Clip	
57	LOOP003	(25)	0P3	Spring CLip	
58	LOLP004	(25)	LP4	Spring Clip	
63	M146002	(25)	0S16	Screw	10-24 UNC x 5/8 in
64	M14J011	(25)		Screw	10-24 UNC x 7/8 in Tuflok
65	L00S034	(10)	0S34	Screw	1/4 in-20 UNC x 3/4 in
66	L00S162	(25)	0S162	Screw	1/4 in - 28 UNF x 3/8 in
67	L01E058	(5)		Screw	
68	L00S252	(10)	0S252	Screw	1/4 in-20 UNC x 5/16 in
69	L0CS399	(10)	0S261,CS399	Screw	10-32 UNF x 3/16 in
70	L00S237	(10)	0S237	Screw	
71	M14J010	(10)		Screw	8-36 UNF x 5/8 in Tuflok
72	L01E057	(10)		Screw	Tuflok
73	M14J008	(10)		Screw	1/4 in-20 UNC x 3/4 in Tuflok 8-32 UNC x 1/8 in
74	L00S175	(10)	0S175	Screw	
78	LOOU013	(10)	0U13	Spring	
79	L00U022	(5)	0U22	Spring	
80	L00U035	(25)	0U35	Spring	
81	L00U036	(2)	0U36	Spring	
82	L00U037	(5)	0U37	Spring	
83	LOOU081	(5)	0U81	Spring	
86	LOCW024	(25)	CW24	Spring Dowel	1/8 in dia. x 5/8 in
87	L004006	(25)	046	Taper Pin	3/16 in x 7/8 in
89	L00W114	(20)	0W114	Retaining Clip	
90	P14J032	(5)		Plunger	
91	L00W116	(4)	04116	Stud	
92	L004117	(5)	0W117	Knob	
94	L00W119	(5)	04119	Bush	
95	L004215	(5)	04215	Plunger	
96	L03J025	(5)		Stud	
97	L004105	(5)	0W105	Stud	
99	L05E281	(5)		Labe	
100*	LOO4201	(10)	0W201	Stud	
101*	L00W198	(10)	0W198	Spring Peg	


* 313 Parts




Index No.	Part No	Equal to	Part	Serial No,
1*	E14J041		Drive Pulley and Sprocket Shaft Assembly 40 Hz - complete with 9,33,84 and 85	
2*	E14J042		Drive Pulley and Sprocket Shaft Assembly 50 Hz - complete with 9,33,84 and 85	
3*	E14J043		Drive Pulley and Sprocket Shaft Assembly 60 Hz - complete with 9,33,84 and 85	
4*	E14J040		Shaft	
5*	E14J065		Pulley and Sprocket	60 Hz
6*	E14J011	96R	Pulley and Sprocket	40 Hz
7*	E14J010	97R	Pulley and Sprocket	50 Hz
8	F14R001	911Z	Main Drive Sprocket	
9.	E14J053		Gear - part drilled	
10	E14J018		Clutch Coupling	
11	E14A053	11R	Adjusting Plate	
12	F14R003	13R	Intermediate Sprocket	
13	F14R004	15R	Collar	
14	E14A013	17R	Conveyor Jogger Cam Lever	
15*	F14R301	2R-3	Chain with 90	
16	F14R006	20R	Chain with 90	
18*	F14R302	82R	Gear Guard	
19	E14J039		Handwheel Assembly - complete shown as 21, 22 and 50	
20	E05E278		Label	
21	E14J038		Handwheel	
22	E14J035		Clutch Insert	
23	E14N101		Cover Plate	
24	E14J023		Plunger Bracket	
25	E14J028		Friction Pad Assembly	
26	E14J031		Pivot Post	
27	E14J025		Thrust Lever Assembly	
28	E14J019		Bracket	
29	E14R197		Solenoid 22-29V 50/60 Hz	
30	F14A007	A1 3P	Locking Insert	
31	E14R154		Bracket	
32	F14J007	281211250P	Microswitch	
33*	E14J068	3R-2	Pulley - part drilled	
34*	F14R202	5R-2	Belt	

* 313 Parts

Note: The 'V' Belts for items 5,6 and 7 are shown on 82



Index No.	Part No.	Equal to	Part	Serial
50	M14R001	(25)	Spring clip	
51	LOOP002	(25)	Spring clip	
52	LOLP004	(25)	LP4 Spring clip	
53	LOCP006	(25)	CP6 Spring clip	
54	M14R004	(25)	Spring clip	
60	LOCR153	(10)	CR153,OR21 Washer	
61	L02A084	(10)	Washer	
62	L00R003	(25)	OR3 Washer	
63	L00R025	(10)	OR25 Washer	
64	L00R015	(10)	OR15 Washer	
65	L0LR008	(25)	LR8 Washer	
68	LOOS018	(25)	0518 Screw	10-24 UNC x 7/8 in
69	M14J014	(10)	Screw	10-32 UNF x 3/16 in Tuflok
70	L00S009	(25)	059 Screw	10-32 UNF x 1/2 in
71	L00S036	(10)	0536 Screw	1/4 in-20 UNC x 1 in
73	L00S171	(10)	05171 Screw	1/4 in-20 UNC x 1/4 in
74	L01E053	(5)	Screw	Tuflok
75	L00S073	(10)	0573 Screw	10-24 UNC x 1/2 in
76	L00S003	(25)	053 Screw	8-32 UNC x 3/8 in
77	LOCS419	(25)	CS419 Screw	6-32 UNC x 1/4 in
78	L0CS343	(25)	CS343 Screw	6-32 UNC x 3/8 in
79	M14R002	(25)	Nut	6-32 UNC
80	L0C1072	(25)	CT72 Nut	4-40 UNC
82*	M14R007	(25)	Taper Pin HT	11/64 in (No.1) x 1.1/4 in
83	L04E067	(5)	Spring	
84	M14J005	(25)	Taper Pin HT	11/64 in x (No. 3/4 in
85*	M1441002	(25)	Taper Pin HT	3/16 in x 1 in (Black)
86	L0044141	(3)	0W141 Collar (2 screw fixing)	
87	M14R008	(10)	Grooved Pin	3/16 in x 1.1/4 in
88	P14J032	(5)	Plunger	
89	L00U035	(25)	OU35 Spring	
90	LOCW704	(5)	CW704 Link	
91	L02J131	(5)	Spacer	
93*	L0LW083	(10)	LW83 P-Clip	
* 313 Parts				




Index No.	Part No.	Equal to	Part	Serial
1*	F 104	5R-3	Guard	
2	F...031		Adjusting Arm	
3*	F14R305		Shaft	
4*	F14R306		Paper Stop	
5	F14R033	42R	Adjusting Collar	
6	F14R204	10R-2	Operating Arm	
7*	E144087	9R-3	Paper Platform	
8*	F14R310	10R-3	Paper Def--tor	
9	E144029	1L-2	Lever	
10*	F14R309	11R-3	Feeler Spindle	
11	E14A138		Lever	
12*	F14R311		Paper Stop Assembly complete with 3,4 and 5	
50	LOOP005 (25)	OP5	Spring Clip	
51	LOOP006 (25)	OP6	Spring Clip	
55	LOOR022 (10)	OR22	Washer	
56	LOCR003 (25)	CR3	Lock Washer	
57	LOCR153 (10)	CR153,OR21	Washer	
58	LOOR001 (10)	OR's	Washer	
63	M14R009 (25)		Screw Tuflok	8-32 UNC x 1/4 in
64	LOOS009 (25)	OS9	Screw	10-32 UNF x 1/2 in
65	14A009 (25)	OS10	Screw	10-32 UNF x 5/8 in
66	LOOS015 (25)	OS15	Screw	10-24 UNC x 1/2 in
67*	LOOS017 (25)	OS17	Screw	10-24 UNC x 3/4 in
68	LOOS175 (10)	OS175	Screw	8-32 UNC x 1/8 in
69	M14R005 (10)		Screw Tuflok	8-32 UNC x 1/4 in
70	LO1E054 (5)		Screw Tuflok	
71	M14J006 (5)	9R-2	Pivot Screw	
72	LOOS280 (5)	OS280	Screw	10-32 UNF x 3/8 in
73*	LOCS411 (4)	CS411	Adjusting Screw	10-24 UNC x 1/4 in
78	LOOT011 (10)	O111	Nut	10-32 UNC x 3/16 in
79*	LOHT052 (10)	H152	Lock Nut	10-24 UNC
83	LOOU045 (25)	OU45	Spring	
84	LOOU046 (25)	OU46	Spring	
86	LOOU083 (10)	OU83	Spring	
87	LOOU084 (10)	OU84	Spring	
90	LOCW024 (25)	CW24	Spring Dowel	1/8 in dia. x 5/8 in
91	LOO4041 (25)	OW41	Spring Dowel	1/8 in dia. x 11/16 in
92	LOOD142 (10)	OO42	Feeler	
94	LOO4005 (10)	OW5	Taper Pin	No.2 x 3/4 in
95	LOO4203 (5)	OW203	Steel Ball	
96	LOO4068 (5)	OW68	Spring Peg	

* 313 Parts


IMPRESSION CYLINDER

E2




Index No.	Part No.	Equal to	Part	No.
52	LOOP014 (25)	OP14	Spring Clip	
53	L00P015 (25)	OP15	Spring Clip	
57	L00R003 (25)	OR3	Washer	
59	L00R018 (10)	OR18	Washer	
60	LOC134 (25)	CR134	Lock Washer	
61	L00R025 (25)	OR25	Washer	
62	L00R067 (25)	OR67	Lock Washer	
63	L00R078 (10)	OR78	Shim Washer	
64	L00R084 (10)	OR84	Shim Washer	
67	LOOS004 (25)	OS4	Screw	8-32 UNC x 1/2 in
68	L01A042 (10)		Screw	8-32 UNC x 3/4 in
69	M14N008 (25)		Screw	Tuflok
70	L00S033 (25)	OS33	Screw	1/4 in-20 UNC x 1/2 in
71	L00S034 (10)	OS34	Screw	Tuflok
72	L00S076 (25)	OS76	Screw	1/4 in-20 UNC x 5/8 in
73	M14M001 (10)		Screw	1/4 in-20 UNC x 3/4 in
74	L00S098 (10)	OS98	Screw	8-32 UNC x 3/8 in
75	L00S124 (10)	OS124	Screw	1/4-20 UNC x 1/2 in
76	LOOS181 (10)	OS181	Screw	8-32 UNC x 5/8 in
78*	L01E065 (5)		Adjusting Screw	8-36 UNF x 3/8 in
79*	L00S248 (5)	748	Screw	
80*	P14A142 (5)		Screw and Cap	
84	M14M008 (10)		Nut	10-32 x 3/4 in
85	L001020 (5)	0720	Nut	8-32 UNC
86	L001025 (10)	0125	Nut	11/16 in - 24 NS
87*	L00T023 (10)	0723	Nut	7/16 in - 32 NS
90*	L00U082 (5)	OU82	Nut	10-32 UNF
92	L00W129 (5)	OW129	Spring	
93	L00W128 (5)	OW128	Spindle	
94	L001030 (25)	OW30	Knob (drilled one side)	
95	L05E380 (10)		Spring Dowel 1/16 in dia. x 7/16 in	
98	L00W120 (3)	OW120	Label	
99	L00W121 (10)	OW121	Segment	
100	P140054 (4)		Stud	
101	L00W125 (5)	OW125	Felt Collar	
102*	L00W126 (5)	OW126	Bearing	
103	L00W216 (4)	OW216	Stud	
104*	P140046 (10)		Gripper Finger	
105	L02J028 (5)		Stud Tuflok	
			Spacer	

* 313 Parts




Index No.	Part No	Equal to	Part	Serial No.
1*	E14D012		Arm	
2	E14A023	38L	Feeler Pawl	
4*	E14D023		Bracket	
5*	E14D027		Cover	
6	E14R218		Solenoid	
7*	E14D028		Slide Plate	
8	E05J015		Eccentric	
9*	See D3-10		Safety Spring Lever	
10*	F14J202	7J-2	Pivot Stud	
52	LOCP009 (25)	CP9	Spring Clip	
55	LOOP005 (25)	0P5,LP5	Spring Clip	
56	LOCP003 (25)	CP3	Spring Clip	
59*	LOCR007 (25)	ATT	Lock Washer	
63*	LOCR003 (25)	CR3	Lock Washer	
64*	L00R008 (10)	0R8	Washer	
66*	LOOS015 (25)	0515	Screw	10-24 UNC x 1/2 in
69	L00S034 (10)	0S34	Screw	1/4 in-20 UNC x 3/4 in
72*	L0CS343 (25)	CS343	Screw	6-32 UNC x 3/8 in
73*	L01E062 (10)		Screw	
74*	L01E052 (5)		Screw	
75	M14J008 (10)	0S35	Screw	1/4 in-20 UNC x 3/4 in Tuflok
76	LOCS420 (10)	CS420	Screw	8-32 UNC x 5/8 in
78*	1001030 (10)	0730	Nut	6-32 UNC
79*	M14M009 (10)		Nut	10-32 UNC
85	LOOU013 (10)	0U13	Spring	
87*	L04A146 (5)		Spring	
90*	L02J152 (4)		Spacer	
91	L0CW538 (5)	CW538	Insulator - not shown	
92	L035211 (5)		Peg	
94	LOOW116 (4)	0W116	Stud	
95	M1411012 (4)		Bush (Machines with Chain Pile Delivery)	
96	See F5-19		Stud	

* 313 Parts




Index No.	Part No.	Equal to	Part	Serial No.
1*	F14N301		Cylinder - complete with 2-4,6,7,17,19-21	
2*	F14N302	3N-3	Gear	
3	F14N201	10N-2	Tension wheel	
4	F14N202	11N-2	Screw	
6*	F14N303	4N-3	Tension shaft - complete	
7*	F14N304	6N-3	Clamp	
8*	E14C005 "		Shaft - complete with Taper and Self-aligning Bearings	From 16D554
9	F14M030	30M	Ring Nut	
10	F148005	31M	Lock Nut	
11	F14N205	20N-2	Adjusting Link	
12	F14N206	5N-2	Retainer - L.H.	
13	F14N207	68=2	Retainer - R.H.	
14	F14N013	75M, 50N	Plate	
16*	F14N305	7N-3	Blanket (Black)	
17*	F14N306	5N-3	Retaining Bar	
18	F14M006	50M	Grease Nipple	
19*	F14N203	14N-2	Support	
20*	F14N204	15N-2	Bracket	
21*	F14N307	2N-3	Cylinder	
51	LOOP015	(25) 0P15	Spring clip	
56	LOCRI34	(25) CR134	Lock washer	
57	LOOR003	(25) OR3	Washer	
58	LOOR018	(10) OR18	Washer	
59	LOCRI53	(10) CR153	Washer	
60	LOOR078	(10) OR78	Shim washer	
61*	LOOR053	(10) OR53	Spacer	
65	M14N008	(25)	Screw Tuflok	1/4 in-20 UNC x 1/2 in
66	L00S034	(10) OS34	Screw	1/4 in-20 UNC x 3/4 in
67	L00S372	(10) CS372	Screw	1/4 in-20 UNC x 5/8 in
68	L00S076	(25) OS76	Screw	8-32 UNC x 3/8 in
69	814M001	(10)	Screw	1/4 in-20 UNC x 1/2 in
70*	M14P012	(10)	Screw	10-32 UNF x 3/8 in
71	L00S231	(10) OS231	Screw	
72*	L0CS363	(10) CS363	Screw	10-24 UNC x 1/2 in
73*	L00S014	(25) OS14	Screw	10-24 UNC x 3/8 in
78	LOOT020	(5) O720	Nut	
79	LOOT025	(10) O725	Nut	7/16 in-32 NS
85	L00W030	(25) OW30	Spring Dowel	1/16 in dia. x 7/16 in
86	P14D054	(4)	Felt Collar	
88	L00W128	(5) OW128	Knob	
89	L00W129	(5) OW129	Spindle	
90	L00W130	(5) OW130	Sleeve	
91	L004120	(3) OW120	Segment	
93*	LOCW024	(25) CW24	Spring Dowel	1/8 in dia. x 5/8 in
94*	LOCW036	(25) CW36	Spring Dowel	3/32 in dia. x 5/8 in
95*	L0HW377	(5) HW377	Spring Dowel	1/8 in dia. x 1/2 in
96*	L00W027	(10) OW27	Dowel	1/4 in dia. x 1.1/4 in

* 313 Parts




Index No.	Part No.	Equal to	Part	Material No.
1	E10F089		Front Cover	
2	E10F046	910F046F99	Edging Strip	
3	F14N017	3003RT	Label	
4	E10F085		Back Panel	
5	E10F088		Support	
6	E04A080	804A080J99	Spring	
7	F14N018		Pump	
9	E10F025	910F025W99	Reservoir	
10	E10F110		Motor	24V 50/60 Hz
11	F14E026		Plug	
12	E10F086		Motor Cover	
13	E10F041	910F041C99	Pipe	10 in
15	E10F033	910F033199	Pipe Connector	
17	E10F115		---- Pipe Connector	
18	E10F055		Pipe	20 in CPD
19	E14R235		Pump Extension Harness CPD	
20	E10F116		Pipe	7 in
21	E10F117		Pipe	20 in CPD
50	LOCP003	(25) CP3	Spring Clip	
51	LOCP004	(25) CP4	Spring Clip	
52	M14N001	(25)	Spring Clip	
53	LOCP005	(25) CP5	Spring Clip	
54	LOCP013	(25) CP13	Spring Clip	
56	L02A079	(10)	Washer	
57	LOCR051	(25) CR51	Washer	
58	L02A057	(4) 802A057M99	Washer (plastic)	
59	LOHR010	(10) HR10	Washer	
60	LOHR023	(25) HR23	Lock Washer	
61	LOHR017	(25) HR017	Lock Washer	
62	LOCR134	(25) CR134	Spring Washer for 68 (not shown)	
65	L0LS015	(10) LS15	Screw	M4 x 10mm
66	M14N005	(5) 222711061P	Bolt	M3 x 35mm
67	LOHS009	(25) HS9	Screw	M4 x 12mm
68	L005036	(10) OS36	Screw	1/4 in-20 UNC x 1 in
69	M14P013	(5)	Screw	1/4 in-20 UNC x 2.1/4 in
70	LOLT005	(25) LT5	Nut	M4
71	LOHW104	(10) HW104	Ty-rap	
72	P10E010	(3) 910E010F99	Stud	
73	L02J084	(4) 802J084Q99	Spacer	
74	L02J085	(10) 802J085L99	Spacer	
75	L04A140	(5)	Drive Spring	
76	P10F092	(5)	Spacer Tube CPD	
77	M13Y006	(5)	Clamp	




Index No.	Part No.	Equal to	Part	Serial No.
1*	E10F123		Trough	
2*	E10F126		Spray Tube	
3	E10F026	910F026R99	Bracket - R.H.	
4	E10F027	910F027M99	Bracket - L.H.	
5*	E10F125		Hose	
6*	E10F129		Trough Cover	
7	E05E253		Label	
8*	F14N308	624N-3	Cleaning Roller - Sponge	
9	E10F078	625N	Hub - L.H.	
10*	F14N311	626N-3	Hub - R.H.	
11	E10F060	630N	Sprocket	
12	F14N021	682N	Chain (39 links) with 90	
13*	F14N309	641N-3	Shaft	
14*	F14N310	634N-3	wiper roller - complete with 62 and 87	

* 313 Parts




Index No.	Part No.	Equal to	Part	Serial h
50	L0CR039	)	CR39	Shim Washer 0.077 in
51	LIJCR108	(10)	CR108	Washer
52	LOHR049	(10)	HR49	Wave Washer
53	L0CR064	(10)	CR64	Washer
54	L0CR009	(10)	CR9	Washer
55	L0CR128	(25)	CR128	Lock Washer
56	L0CR134	(25)	CR134	Spring Washer.
58	LOOS018	(25)	OS18	Screw 10-24 UNC x 7/8 in
59	M14N003	(10)		Screw 1/4 in-20 UNC x 3/4 in
60	L0SC362	(10)	CS362	Screw 5/16 in-18 UNC x 1/2 in
61	L0CS379	(10)	CS379	Screw 8-32 UNC x 5/16 in
62	L0CS380	(10)	CS380	Screw 6-32 UNC x 5/16 in
63	L0CS400	(2)	CS400	Adjusting Screw
64	M14N004	(20)	218530623P	Screw 8-32 UNC x 7/16 in
65	M14N007	(10)	218530626P	Screw 8-32 UNC x 7/8 in
66	L0OS164	(10)	OS164	Screw 10-32 UNC x 1/8 in
67	L0CS361	(10)	CS361	Screw - R.H. 1/4 in-20 UNC x 3/4 in
68	L0OS035	(10)	OS35	Screw - L.H. 1/4 in-20 UNC x 7/8 in
70	L01J018	(25)		Nut 8-32 UNC
71	L0DT001	(25)	DT1	Nut 6-32 UNC
72	M14G005	(10)	218811031F	Nut 1/4 in-20 UNC
76	L0CW405	(25)	CW405	Spring Dowel 1/8 in dia. x 3/4 in
77	L0CW445	(25)	CW445	Spring Dowel 1/8 in dia. x 1/4 in
78	L0CW705	(5)	CW705	Bearing
79	L0CW706	(5)	CW706	Pivot Stud
80	L0CW710	(5)	CW710	Side Plate - L.H.
81	L0CW711	(5)	CW711	Locking Collar
82	L0CW712	(5)	CW712	Side Plate - R.H.
83	L0CW714	(5)	CW714	Stud
84*	L0CW716	(4)	CW716	Spacer
85	LOHW039	(5)	HW39	Bearing
86	LOHW361	(5)	HW361, CW726	Bearing
87	L0OW182	(10)	OW182	Bearing
89	LOHW057	(50)	HW57	Nylon Plug
90	L0CW704	(5)	CW704	Link

* 313 Part




Index No.	Part No.	Equal to	Part	Serial No
1*	E10H015		Operating Shaft	
2	F14N022	656N	Operating Arm	
3	F14N023	660N	Operating Plate	
4	F14N024	664N	Connecting Link for 3 and 8	
5	F14N025	666N	Drive Sprocket	
6	F14N026	667N	Spindle for 5 -	
7	F14N027	669N	Clutch Cam Sprocket	
8	F14N028	671N	Operating Arm	
9	F14N029	679N	Idler Sprocket - complete with 98	
11	F14N030	683N	Chain (63 Links)	
12	F14N031	685N	Chain Guard	
13	E14R195		Solenoid 23/25v 50/60 Hz	
14	E10F100		Stop for 13	
15	E10F097		Link for 13	
16	E10F099		Arm for 1 and 15	
19	E14A065		Blanking Disc	

* 313 Part




Index No.	Part No.	Equal to	Part	Serial No
50	LOCP002	(1)	CP2	Spring Clip
51	LOCP009		CP9	Spring Clip
56	LOCR121	(10)	CR121	Washer
57	LOCR036	(25)	CR036	Packing Washer
58	M14N009	(10)		Thrust Washer
59	LOCR125	(10)	CR125	Washer
60	L02A086	(10)		Washer
61	LOCR147	(10)	CR147	Washer
62	L0CR153	(10)	CR153,0R21	Washer
65	LOOS009	(25)	059	Screw 10-32 UNF x 1/2 in
66	LOOS008	(25)	058	Screw 10-32 UHF x 3/8 in
68	M14N006	(10)		Screw 10-32 UHF x 5/16 in
69	M14N002	(25)		Screw 10-32 UHF x 1/4 in
70	1005363	(10)	CS363	Screw 10-24 UNC x 1/2 in
78	LOCT072	(10)	CT72	Nut 4-40 UNC
83	L0CU237	(5)	CU237 ----	Spring
84	L04A141	(10)		Spring
89	L035223	(5)		Peg
90	LOCW444	(25)	CW444	Spring Dowel 3/32 in dia. x 7/8 in
91	LOCW703	(10)	CW703	Link Pin
92	LOCW704	(5)	CW704	Connecting Link
93	LOCW708	(10)	CW708	Link Pin
94	LOCW709	(5)	CW709	Collar
95	LOCW715	(10)	CW715	Stud
96	LOCW717	(5)	CW717	Bearing
97	LOCW720	(5)	CW720	Clutch Cam Plate
98	LOCW725	(10)	CW725	Bearing
99	LOCW724	(4)	CW724	Eccentric
100	L03W079	(2)		Spring Peg
101	M14N010	(5)	236350536P	Bearing




Index No.	Part No.	Equal to	Part	Serial No.
1*	E148069		Combination Plate Cylinder - complete with 2,13,19,20-23, 25,50,52,53,57-64,65,69,72,74, 81,82,87,92 and 100-102	
2*	F14P302	3P-3	Gear	
3*	E05E379		Scale	
4	F14P004	27R	Guard	
5	F14R303	4R3	Guard	
6*	E148042		Shaft - complete with Taper and Self-aligning Bearings	
7	F14M006	38P,43N,50M	Grease Nipple	
8	F14M030	3014	Ring Nut	
9	F1411005	31M	Lock Nut	
10	F14N214	18P-2	Plate	
11	F14P202	14P-2	Retainer - L.H.	
12	F14P203	15P-2	Retainer - R.H.	
13*	E148057		Plate Tension Shaft Assembly	
14	F14P010	221P	Arm	
15*	E04J056		Spring	
16*	E148059		Pivot Shaft Assembly	
17	E1413070		Hook Bar Assembly	
18*	E148063		Hook Bar - Lower	
19*	E01E042		Tension Screw	
21*	E148061		Shaft	
22*	E148068		Clamp Body Assembly	
23*	E148067		Friction Pad	
24	F14P206	25P-2	Release Lever	
25*	E14B055		Plate Cylinder - only (not shown)	

* 313 Parts




Index No.	Part No.	Equal to	Part	Serial No.
50	LOOP020	(25) OP20	Spring Clip	
51	LOOP015	(25) OP15	Spring Clip	
52	L02E008	(10)	Shim washer (as required)	0.2mm
53	P148027	(10)	Washer	
54	LOOR003	(25) OR3	Washer	
55	LOCR153	(10) CR153,OR21	Washer	
56	LOCR079	(25) CR79	Lock Washer	
57	LOOR001	(25) OR1	Washer	
58	LOOR010	(10) OR10	Washer	
59	LOOR025	(10) OR25	Washer	
60	LOOR081	(10) OR81	Washer	
63*	M14M003	(5)	Screw	1/4 in-28 UNF x 1/2 in
64	M14M002	(5)	Screw	8-32 UNC x 2.1/4 in
65	M14P012	(10)	Screw	10-32 UNF x 3/8 in
67	LOOS014	(25) OS14	Screw	10-24 UNC x 3/8 in
68	LOOS017	(25) OS17	Screw	10-24 UNC x 3/4 in
69	LOOS131	(10) OS131	Screw	1/4 in-20 UNC x 3/8 in
70	LOOS034	(10) OS34	Screw	1/4 in-20 UNC x 3/4 in
71	LOOS039	(10) OS39	Screw	
72	M14G008	(10)	Locking Screw	5/16 in-18 UNC x 1/2 in
73*	LOOS244	(5) OS244	Screw	centre
74*	LOCS372	(10) CS372	Screw	1/4 in-20 UNC x 5/8 in
75	LOOS155	(10) OS155	Screw	10-24 UNC x 3/16 in
78*	LOOS243	(5) OS243	Screw - L.H. and R.H.	
79	M14P001	(10)	Screw	1/4 in-20 UNC x 3/8 in
80	M14P002	(10)	Screw	10-32 UNF x 1/4 in
81	LOOS076	(10) OS76	Screw	10-24 UNC x 1/4 in
82	M1411006	(10) L00582	Screw	6-32 UNC x 3/8 in
83*	M1411010	(10)	Screw	1/4 in-28 UNF x 5/16 in Tuflok
85	LOHT052	(10) HT52,OT1	Nut	10-24 UNC
86	LOOT020	(5) O120	Nut	11/16 in-24 NS
87	LOOT008	(25) O78	Lock Nut	1/4 in-20 UNC
88	LOOT026	(3) O726	Lock Nut	1.1/8 in-24 NS
92	LOCU250	(5) CU250	Spring	
93	LOOU039	(10) OU39	Spring	
97	P14D054	(4)	Felt collar	
98*	LOHW008	(25) HW8	Spirol Pin	3/32 in x 1/2 in
99*	LOOW130	(5) OW130	Sleeve	
100*	P148071	(10)	Stop	
101	LOOW006	(25) OW6	Taper Pin	3/16 in x 7/8 in
102	LOOW028	(25) OW28	Spring Dowel	1/16 in dia. x 2 in
103	LOOW031	(25) OW31	Spring Dowel	1/16 in dia. x 5/8 in
105	LOOW131	(10) OW131	Print Indicator	
106	LOOW132	(10) OW132	Pin - L.H. and R.H.	
107	LOOW133	(5) OW133	Stud - centre	
108	LOOW214	(3) OW214	Pivot Stud - centre	
109	M14P005	(5)	Stud - L.H. and R.H.	
110	P148087	(3)	Adjustment Plate	
111	P148088	(3)	Screw	

* 313 Parts




Index No.	Part	Equal to	Part	Serial NC
1*	F140301	10-3	Jogger Camshaft - complete	
2	E14A022	920	Jogger Cam (half drilled)	
3*	F1414302	80-3	Gear (half drilled)	
4*	F1441303	90-3	Feeler Cam (half drilled)	
5*	F140304	100-3	Drum Operating Cam (half drilled)	
6	F144005	50	Conveyor Jogger Cam	
7*	F14.4305	20-3	Deflector	
8	F144007	560	Screw Shaft	
9	F14008	570	Friction Plate	
10	F1441009	584	Spring	
11	F140010	144	Sleeve	
12	F144011	594	Cap	
13	F1441012	604	Adjusting Knob	
14*	F144306	-7Q-3	Idler Gear	
15	F140014	620	Friction Disc	
16	F140015		Lever	
17*	F140307	134-3	Roller Assembly	
18*	F140308	140-3	Intermediate Gear	
19*	F140309	150-3	Stud	
21*	F144310	184-3	Cover	
22	F140020	490	Deflector Roller	
23	F144021	484	Ring	
24*	F144311	160-3	Auxiliary Roller Assembly	
25	E14U006	554	Bearing - L.H. end	
50	LOOP016	(25) OP16	Spring Clip	
51*	LOCP013	(25) CP13	Spring Clip	
56	LOCRO79	(10) CR79	Lock Washer	
57	LOOR011	(10) OR11	Washer	
58	LOOR019	(10) OR19	Washer	
63	LOOS014	(25) OS14	Screw 10-24 UNC x 3/8 in	
64	L00S159	(10) OS159	Screw 1/4 in-28 UNF x 3/16 in	
65	L00S206	(5) OS206	Screw	
66	LOOS015	(25) OS15	Screw 10-24 UNC x 1/2 in	
70	L00T028	(10) OT28	Nut 3/8 in-24 UNF	
73	L00U042	(10) OU42	Spring	
75	M140003	(25) OW46	Taper Pin 11/64 in x 1.1/8 in	
77	L004046	(25) OW51	Spring Dowel 5/32 in dia. x 1 in	
78	LOCW051	(5) OW110	Collar	
79	LOOW110	(5) OW110	Bush	
80	10CW766	(10) CW766	Taper Pin 5/32 in x 7/8 in	
81	M10002	(25) CW767	Pin 3/16 in x 1 in	
82	LOCW767	(2) CW767	Bearing	

* 313 Parts




Index No.	Part No	Equal to	Part	Serial No.
1*	F14Q312	17Q-3	Cylinder - complete 1.6'h 2,3, 4,5,6,8,10 and 11	
2	F14Q024	39Q	Gripper Disc	
3*	F140313	5Q-3	Tie Rod	
4	F14Q026	384	Gripper Disc Hub	
5	F144027	35Q	Disc Collar	
6*	F114314	11Q-3	Gear	
7*	F144315	12Q-3	Guard	
8*	E14Q028		Shaft A, End Plates B and 78 Assembly	
9*	E14U010	4Q-3	Bearing - L.H.	
10	F14Q031	16Q	Cam	
11*	E14U020	19Q-3	Gripper Shaft	
* 313 Parts				
50	LOOR003	(25)	OR3	Washer
51	LOOR019	(10)	OR19	Washer
56	LOOS003	(25)	OS3	Screw 8-32 UNC x 3/8 in
57	L005189	(10)	OS189	Lock Screw 1/4 in-20 UNC x 1/8 in
58	M14J012	(10)		Set Screw 1/4 in-20 UNC x 1/2 in Tuflok
59	L0CS372	(10)	CS372	Screw 1/4 in-20 UNC x 5/8 in
60	M14V004	(10)		Screw 10-24 UNC x 3/8 in
61	LOOS015	(25)	OS15	Screw 10-24 UNC x 1/2 in
63	L00S035	(10)	OS35	Screw 1/4 in -20 UNC x 7/8 in
64	LOOS161	(10)	OS161	Set Screw 1/4 in -28 UNC x 5/16 in
66	LOHT052	(10)	HT52	Nut 10-24 UNC
70	LOOU019	(5)	OU19	Spring
75	L00W137	(10)	OW137	Kicker
76	L00W138	(10)	OW138	Gripper
77	L00W139	(10)	OW139	Support
78	M14Q004	(25)		Taper Pin 3/16 in x 1.1/8 in
79	L0CW767	(2)	CW767	Bearing




Index Part No.	Part No.	Equal to	Part	Serial No.
1*	E14V041		Platform	
2*	F14S301	2S-3	Front Roller	
3	F14S002	3S	Cover	
4	F14S003	4S	Bearing	
5*	F14S302	3S-3	Ball carrier	
6*	F14S303	4S-3	Belt (set of 3)-	
7	E14V007	11S	Centre Guide	
8*	F14S304	5S-3	Retainer	
9*	E05E299		Scale	
10*	F14S306	7S-3	Shaft	
11*	F14S307	8S-3	Tie Rod	
12	F14S010	23S	Adjusting Shaft	
13	F14S011	33S	Chain - 72 Links	
14	F14S012	34S	Chain - 61 Links	
15*	F14S308	10S-3	Back Roller	
16	F14S014	37S	Bearing Bracket - L.H.	
17	F14S015	38S	Bearing	
18	F14S016	39S	Bearing Bracket R.H.	
19	F14S017	45S	Drive Gear	
20	F14S018	46S, 185V	Adjusting Nut	
21	F14S019	49S	Gear/Sprocket Unit	
22	F14S020	50S	Gear/Sprocket Unit	
23	E14V019		Belt and Guide Adjusting Knob for L.H. side - complete with 64	
24	E14V028		Belt and Guide Adjusting Knob for R.H. side - complete with 64 and 79	
25*	F14S309	31-3	Adjusting Screw - L.H. side	
26*	F14S310	57-3	Adjusting Screw - R.H. side	
27*	F14S311	61-3	Scissor Bracket	
28*	F14S312	41-3	Shaft	
29	F14S027	541	Bearing	
30	F14S028	521	Sprocket	

* 313 Parts




Index No.	Part No.	Equal. to	Part	Serial NC
50	L00P006	0P6	Spring Clip	
51	L00P017 (k)	0P17	Spring Clip	
53	L00R022 (10)	0R22	Washer	
54	L00R003 (25)	0R3	Washer	
56	M14N008 (25)		Screw Tuflok 1/4 in-20 UNC x 1/2 in	
57	L00S033 (25)	0S33	Screw 1/4 in-20 UNC x 5/8 in	
58	L00S052 (10)	0S52	Screw 1/4 in-28 UNF x 1.1/4 in	
59	L00S063 (10)	0S63	Screw 5/16 in-24 UNF x 5/8 in	
60	L00S100 (.5)	0S100	Screw 10-32 UNF x 1.1/4 in	
61	L00S101 (10)	0S101	Screw 1/4 UNF x 1/2 in	
62	L00S125 (10)	0S125	Screw	
63	L00S126 (5)	0S126	Screw (R.H. Front)	
64	L00S162 (25)	0S162	Screw 1/4 in-28 UNF x 3/8 in	
65	L00S170 (10)	0S170	Screw 1/4 in-20 UNC x 1/4 in	
66	L00S189 (10)	0S189	Lock Screw 1/4 in-20 UNC x 1/8 in	
67	L00S176 (10)	0S176	Screw 8-32 UNC x 1/8 in	
68	L00S002 (25)	0S2	Screw 8-32 UNC x 1/4 in	
69	L00S236 (10)	0S236	Screw	
71	L011T055 (10)	HT055	Nut 1/4 in-28 UNF	
76	L00W144 (25)	0W144	Steel Ball	
77	L00W145 (10)	0W145	Bracket	
78	L00W146 (20)	0W146	Distance Tube	
79	L05E280 (5)		Label	




Index No.	Part No.	Equal to	Part	Serial
1	E14V022	11	Jogger Side Guide - L.H.	
2	E14V023	27	Jogger Side Guide - R.H.	
3	F147001	91	Adjusting Knob	
4	F141002	11/	Feather	
5	F147003	131	Stud	
6	F147004	161	Feather	
7	F147028		Bracket	
8*	F141301	11-3	Adjusting Screw R.H. - complete with 7, A & B	
9*	F147302	27-3	Adjusting Screw L.H. - complete with 7, A & B	
10	F147008	231	Plate	
12	F14T010	367	Bracket	
13	F147011	297	Lever	
14	F147012	331	Spring Plate	
15	F147013	357	Yoke	
16	F147014	487	Plate	
17	E14V005	461	Lever - R.H.	
18	F141015	401	Push Rod	
19	E14V004	47T	Lever - L.H.	
20	F147025	627	Adjusting Bracket	
21	F141026	667	Tension Weight	
22	F147027	731	Bracket - L.H. and R.H.	


* 313 Parts



Index No.	Part No.	Equal to	Part	Serial N
50	LOOP001	OP1	Spring Clip	
51	L0LP003	(25) LP3	Spring Clip	
52	LOOP010	(25) OP10	Spring Clip	
53	LOOP005	(25) OP5,LP5	Spring Clip	
57	L0OR022	(10) OR22	Washer	
58	L0OR014	(25) OR14	Washer	
59	L0OR025	(10) OR25	Washer	
60	L0OR026	(10) OR26	Washer	
61	L0OR031	(10) OR31	Washer	
	L0OR075	(10) OR75	Shim Washer for 8 and 9 (if required - not shown)	
63	L0OR003	(25) OR3	Washer	
64	LOCRI53	(10) CR156,OR21	Washer	
65	LOCRI45	(25) CR145	Lock Washer	
66	L0OR001	(25) OR1	Washer	
67	M14V003	(10)	Shim Washer	
70	L0CS386	(10) CS386	Screw	10-32 UNF x 1/8 in
71	L0OS002	(25) OS2	Screw - R.H.	8-32 UNC x 1/4 in
72	L0OS100	(5) OS100	Screw	10-32 UNF x 1.1/4 in
73	L0OS102	(10) OS102	Screw	8-32 UNC x 3/32 in
74	L0OS103	(10) OS103	Screw	8-32 UNC x 3/8 in
75	L0OS104	(10) OS104	Screw	8-32 UNC x 3/16 in
76	L0OS105	(10) OS105	Screw	10-24 UNC x 3/8 in
77	L0OS176	(10) OS176	Screw	8-32 UNC x 1/8 in
78	L0OS064	(10) OS64	Screw	1/4 in-28 UNF x 5/8 in
79	L0OS004	(25) OS4	Screw - L.H.	8-32 UNC x 1/2 in
80	L0OS169	(10) OS169	Screw	10-32 UNF x 1/2 in
82	M141008	(10)	Nut	8-32 UNC
83	L0OT032	(10) OT32	Nut	6-40 UNF
84	M14G006	(10)	Nut	1/4 in - 28 UNF
90	L0OU048	(10) OU48	Spring	
91	L0OU049	(10) OU49	Spring	
92	L0OU050	(3) OU50	Spring	
93	L0OU051	(5) OU51	Spring	
94	L0OU052	(3) OU52	Spring	
100	L0O4045	(25) OW45	Spring Dowel	5/32 in x 7/8 in
101	L0OW033	(25) OW33	Spring Dowel	3/32 in dia. x 3/4 in
102	L0OW085	(10) OW85	Plug	
103	L0OW146	(20) OW146	Spacer	
104	L0(1W148	(5) OW148	Stop - L.H.	
105	L0O4149	(5) OW149	Collar	
106	L0OW150	(20) OW150	Steel Ball	
107	P14V017	(3)	Bracket	
108	P14V018	(3)	Bracket	
109	L0OW153	(5) OW153	Sleeve	
110	L0OW154	(3) OW154	Bracket	
111	L0OW155	(3) OW155	Roller	
112	L0OW156	(5) OW156	Spindle	
113	L0OW217	(5) OW217	Spindle	
114	L0OW147	(5) OW147	Cap - R.H.	
115	L01J016	(5)	Nut	8-32 UNC x 5/8 in




Index No.	Part No.	Equal to	Part	Serial No.
1	E14X06u		Side Frame - L.H. - complete with 4, 5, 6, 9, 82, 83, 84, 86, 88, 89, 90 and 91	
2*	E14B075		Side Frame - R.H. - complete with 3, 4, 5, 20, 69, 82, 84, 86, 88, 89, 90 and 91	
3*	E148074		Stop Pin	
5	F14U003	20U	Idler Bush Assembly	
6	F144J004	164U	Water Quantity Plate	
7	F14U005,	39U	Bracket	
8	E14X028	170U	Ductor Cam	
9	F141J006	43U	Ductor Yoke Latch	
10	F14U007	163U	Drive Shaft Pawl	
11*	E14X067		Reservoir	
12	E14X036		Support Plate	
13*	E14X064		Drip Tray	
14	E14X043		Bracket - L.H.	
15	E14X042		Bracket - R.H.	
16	E14X068		Lifting Arm - L.H.	
17	E14X069		Lifting Arm - R.H.	
18*	E14X065		Tie Bar	
19*	E14X072		Lifting Bar	
20	F14U032	217U	Stop Pin	
* 313 Parts				
50	LOOP006 (25)	OP6	Spring Clip	
51	M14R004 (25)		Spring Clip	
52	L0LP004 (25)	LP4	Spring Clip	
56	M14U006 (10)		Shim washer	
57	LOCRO03 (25)	CR3	Lock washer	
58	M14U003 (10)		washer	
62	L0LS013 (25)	LS13	Screw	M4 x 8mm
64	L00S033 (25)	OS33	Screw	1/4 in-20 UNC x 5/8 in
65	L00S034 (10)	OS34	Screw	1/4 in-20 UNC x 3/4 in
66	L00S038 (10)	OS38	Screw	1/4 in-20 UNC x 1 1/2 in
67	L00S105 (10)	OS105	Screw	10-24 UNC x 3/8 in
69	L00S169 (10)	OS169	Screw	10-32 UNF x 1/2 in
70	L00S237 (10)	OS237	Screw	
75	L00U053 (10)	OU53	Spring	
76	L001J054 (10)	01.154	Spring	
77	L00U055 (5)	OU55	Spring	
82	L03W115 (5)		Spring Peg (2 required per Side Frame)	
83	L0HW010 (10)	HW10	Spirol Pin	5/32 in dia. x 1 in
84	M14U011 (10)		Bush	
86	L0HW009 (10)	HW9	Spirol Pin	5/32 in dia. x 1 1/4 in
87	L00W162 (5)	OW162	Plunger	
88	L00W163 (10)	OW163	Spring Peg	
89	L03S220 (2)		Stud	
90	L03S221 (2)		Stud	
91	L03N172 (2)		Pin	
92	M144J004 (10)		View Plug	
93	L00W204 (5)	OW204	Stop Pin	




Index No.	Part	Equal to	Part	Serial N,
3*	F14U301	3U-3	Spindle	
4*	E14X081	4U-3	Shaft Assembly	
5	F14U012	58U	Arm - L.H. and R.H. ends	
6	F14U013	165U	Plate	
7	F14U014	167U	Roller	
8	F14U015	166U	Eccentric Nut	
9*	E14X013	5U-3	Fountain Roller	
10	F14U016	158U	Bush - R.H.	
11	E14X019		Fountain Drive Shaft - complete	
12	F14U017	157U	Friction Bush - L.H.	
13	E14X024		Quantity Control Knob with 58	
14	E14X050		Knob - complete with 58 and 80	
50	LOLP004 (25)	LP4	Spring Clip	
51	LOCP013 (25)	CP13	Spring Clip	
57	M14A009 (25)	OS10	Screw	10-32 UNF x 5/8 in
58	L005162 (25)	OS162	Screw	1/4 in-28 UNF x 3/8 in
59	L00S163 (5)	OS163	Screw	1/4 in-28 UNF x 1 in
60*	L00S167 (25)	OS167	Screw	10-32 UNF x 5/16 in
64	L001033 (10)	0733	Lock Nut	1/4 in-28 UNF
70	L00U058 (10)	0U58	Spring	
71	L00U056 (5)	01156	Spring - L.H.	
72	L00U057 (5)	01157	Spring - R.H.	
73	LOCW024 (25)	CW24	Spring Dowel 1/8 in dia. x 5/8 in	
74	L00W212 (10)	0W212	Spring Peg	
80	L05E283 (10)		Label	
81	L001013 (4)	0W13	Latch	
82*	L00W018 (25)	0W18	Spring Dowel	

* 313 Parts




Index No.	P; t	Equal to	Part	Serial Na
1*	F141303	6U-3	Molleton Roller - complete	
2*	F14U304	71J-3	Molleton Roller	
3*	F14U305	8U-3	Ductor Roller	
4*	F14U306	10U-3	Cover (supplied in pack of 2)	
5	F14U021	94U	Link - L.H.	
6	F14U022	971J	Link - A.H.	
7*	F14U307	11U-3	Cover (supplied in pack of 2)	
8*	F14011	9U-3	Shaft	
10	F14U025	156U	Adjustable sleeve	
11	F14U026	193U	Molleton Release Arm - L.H.	
12	F14U027	194U	Molleton Release Arm - R.H.	
13*	E1413072		Camshaft - complete	
14	E14x058		Cam	
15*	F14U030	-/mnu	Release Cam	
16	E14x049		Knob - complete with 64,94 and 97	
17	E148074		Stop Pin - Back	
18	F14U032	217U	Stop Pin - Front	
19	E148037	208U	Plate	
20	F14U033	210U	Plunger	
21	F14U034	212U	Lever	
50	LOOP001 (25)	OP1	Spring clip	
51	LOOP022 (25)	OP22	Spring clip	
56	L02A092 (10)		Washer - L.H. side	
57	L00R029 (10)	OR29	Washer - R.H. side	
58	LOCRO99 (10)	CR99	Washer (polythene) - top	
59	L00R031 (10)	OR31	Washer (fibre) - bottom	
60*	LOCRO03 (25)	CR3	Lock washer	
63*	L0CS465 (5)	C5465	Screw	10-32 UNF x 1.1/2 in
64	L00S162 (25)	OS162	Screw	1/4 in-28 UNF x 3/8 in
65	L00S205 (10)	OS205	Screw	
66	L00S239 (3)	OS239	Adjusting Screw	
67	L00S262 (10)	OS262	Screw	
68	L00S271 (5)	OS271	Pivot Screw	
72	M14U007 (5)		Nut	1/4 in-28 UNF
73*	8148009 (10)		Nut	10-32 UNF
74	M14U010 (5)	151U	Adjusting Nut	
75	L00T023 (10)	0123	Nut	
80	L00U059 (5)	0U59	Spring	
81	L00U060 (5)	0(160	Spring	
82	L00U061 (5)	0U61	Spring	
83	L00U062 (10)	0U62	Spring	
89	L00W015 (10)	0W15	Spirol Pin	1/8 in dia. x 3/4 in
91	L0CW562 (10)	CW562	Spring Dowel	1/8 in dia. x 3/4 in
93	L00W165 (5)	0W165	Peg	
94	L00(F166 (10)	0W166	Indicator Label	
95*	L02J148 (5)		Spacer	
96	L004203 (5)	0W203	Steel Ball	3/16 in dia.
97	L05E282 (10)		Water Label	

* 313 Parts




Index No.	Part No.	Equal to	Part	Serial N
1*	F14 .0	1311-3	Oscillating Roller	
2*	F1411203	2611-2	Gear and Spool	
3	F1411037	135U,212V	Guide Wheel	
4*	E14X074	1411-3	Support Shaft - Sub Assembly	
5	E14X061		Arm	
6	F14U205	32U-2	Oscillating Gear/Pulley	
7*	F14U209	42U-2	Oscillating Link - complete	
8	F14U040	1291.1	Ball Race	
9*	F1411210	46U-2	Bearing	
10*	F1411211	47U-2	Screw	
11*	F141J213	54U-2	Stud	
12*	F14U212	48U-2	Bracket	
13*	F1411215	35U-2	Tension Arm - complete	
14*	F1411206	3611-2	Arm	
15*	F14U207	37U-2	Bearing	
16*	F1411208	3811-2	Screw	
* 313 Parts				
51	LOOP002	(25) 0P2	Spring Clip	
52	LOOP018	(10) 0P18	Spring Clip	
54	LOOR003	(25) 0R3	Washer for 13 (not shown)	
55	LOOR041	(10) 0R41	Washer	
56	LOOR082	(10) 0R82	Washer	
58	L00R039	(10) 0R39	Spacer	
59	LOOR056	(10) 0R56	Spacer	
60	L00R069	(25) 0R69	Lock Washer	
62	L00S051	(10) 0551	Screw	1/4 in-28 UNF x 7/8 in
63	L00S176	(10) 05176	Screw	8-32 UNC x 3/16 in
64	L00S164	(10) 05164	Screw	10-32 UNF x 1/8 in
65	L00S157	(10) 05157	Screw	10-24 UNC x 3/8 in
71	L00T023	(10) 0723	Nut	10-32 UNF
77	LOCU043	(10) CU43	Spring	
82	L00W204	(5) 0W204	Stop	
83	L00W039	(25) 01439	Spring Dowel	1/8 in dim. x 7/16 in




Index No.	Part "O.	Equal to	Part	Serial
1	F1 001	43V	Support	
2	F14V002	13V	Adjusting Screw for 1	
3	F14V003	7V	Stud for 2 and 56	
4	E14H153	44V	Retaining Arm for 1	
5	F14V004	38V	Support	
6	E14H152	39V	Retaining Arm for 5	
7	F14V005	26V,501V-S	Shut-Off Lever	
8*	F14V301	1V-3	Intermediate Gear	
9*	F14V302	2V-3	Tie Rod	
10	F14V008	34V	Lifting Screw - long	
11	F14V009	216V	Lifting Screw - short	
12	-		Adjusting Nut - see H6-10	
50	LOOP001	(25) OP1	Spring Clip for 78	
51	LOLP003	(25) 1:P3	Spring Clip for 7	
55	LOOS013	(10) OS13	Screw for 1 10-32 UHF x 1 in and 5	
56	L00S036	(10) 0536	Screw for 9 1/4 in-20 UNC x 1 in	
57	L00S212	(5) OS212	Pivot Screw for 7	
58*	M14V005	(3) 31V-3	Screw for 8	
59	L00S214	(3) OS214	Pivot Screw for 1 and 5	
60	LOHS157	(10) HS157	Screw for 3 10-32 UNC x 3/16 in	
65	LOHT050	(10) HT50,OT9	Nut for 58 1/4 in-20 UNC	
70	L00U065	(10) 0U65	Spring for 7	
72	L04A139	(5)	Spring for 4 and 6	
77	L00M169	(10) 0W169	Plug for 3 and 60	
78	L00W176	(10) 0W176	Pin for 4 and 6	
79	L00W047	(25) 0W47	Spring Dowel 5/32 in dia. x 1.3/4 in for 7	
80	L03W067	(5)	Spring Peg for 72	
81	LOHW188	(10) HM188	Roller for 7	

* 313 Parts



Index No.	Pe. h	Equal to	Part	Serial No
1*	F14V303	10V-3	Fountain Roller - complete	
2	F14V020	240V	Ratchet Wheel	
3	F14V021	64V	Operating Plate	
4	F14V022	66V	Pawl	
5	F14V023	238V	Quantity Plate	
6	E14H054		Quantity Control Knob with 61	
7	E14H141		Knob - complete with 61 and 89	
8	F14V024	55V	Support	
9*	F14V304	34V-3	Trough	
12*	F14V305	6V-3	Ductor Blade	
13*	F14V306	4V-3	Lock Spring	
14*	F14V307	5V-3	Clamp	
15*	F14V308	7V-3	Ductor Roller	
16*	F14V309	11T-3	Carrier Shaft	
17*	F14V310	9V-3	Rocker Shaft	
18	F14U012	58U	Support Arm	
19	E14H192		Drip Tray	
20*	E14H312		Ductor Pivot (outside)	
21*	F14V312	32V-3	Adjustment Arm	
22*	F14V313	33V-3	Tie Rod - Rear	
50	LOOP001	(25) OP1	Spring Clip	
51	LOLP004	(25) LP4	Spring Clip	
52	LOCP013	(25) CP13	Spring Clip	
53	M14R004	(25)	Spring Clip	
54	LOCP003	(25) CP3	Spring Clip	
56*	LOCR082	(25) CR82	Washer	
58	LOHS009	(25) HS9	Screw M4 x 12mm	
59	LO1E037	(5) 801E037B99	Adjustment Screw	
60	LO05034	(10) OS34	Screw 1/4 in-20 UNC x 3/4 in	
61	LO05162	(25) OS162	Set Screw 1/4 in-28 UNF x 3/8 in	
62	LO05250	(5) OS250	Stud	
63*	LOCS420	(10) CS420, OS19	Screw 8-32 UNC x 5/8 in	
64*	LOOW195	(4) OW195	Adjustment Screw	
65*	LOOS036	(10) OS36	Screw 1/4 in-20 UNC x 1 in	
66*	LOCS037	(5) CS442	Screw 1/4 in-20 UNC x 1 in	
67	LOOT008	(25) O18	Nut 1/4 in-20 UNC	
72	LOOU054	(10) OU54	Spring	
73	LOOU056	(5) OU56	Spring - L.H.	
74	LOOU057	(5) OU57	Spring - R.H.	
75	LOHU102	(5) HU102	Spring	
76	LOOU069	(10) OU69	Spring	
77*	LOHU108	(4) HU108	Spring	
80*	LOOW196	(2) OW196	Nut	
81	LOOW013	(4) OW13	Retaining Latch	
82	LOOW018	(25) OW18	Spring Dowel 1/8 in dia. x 7/8 in	
83	M14V001	(25)	Spring Dowel 5/32 in dia. x 11/16 in	
84	LOOW162	(5) OW162	Plunger	
85	LOOW178	(5) OW178	Pawl	
86	LOOW179	(5) OW179	Roller	
87*	LOOW180	(5) OW180	Bush	
88	LO3W114	(10)	Spring Peg	
89	LO5E284	(5)	Label	


* 313 Parts



Index No.	Part No.	Equal to	Part	Serial No.
1*	E14H080		Upper Hard Idler Roller	
2*	E14H079		Upper and Lower Soft Idler Roller	
3	F14V040	302V	Carrier Plate - L.H.	
4	F14V041	303V	Carrier Plate - R.H.	
5	F14V042	290V	Retaining Block	
6	F14V043	273V	Carrier Slide - L.H.	
7	F14V044	274V	Carrier Slide - R.H.	
8	F14V045-	275V	Spring Peg	
9*	E14H081		Lower Hard Idler Roller	
10	E14H059	123V	Bearing Arm - L.H.	
11	E14H060	124V	Bearing Arm - R.H.	

* 313 Parts


55	LOOR040	(10)	OR40	Washer
56	LOOR079	(10)	OR79	Shim Washer (as required) for 67
61	L005026	(10)	OS26	Screw 10-32 UHF x 1.1/4 in
62	L00S053	(3)	OS53	Stop Screw 5/16 in-18 UNC x 1/2 in
63	LOHS071	(10)		Screw
64	L00S182	(10)	OS182	Screw 6-32 UNC x 1/4 in
65	L00S186	(10)	OS186	Screw 6-32 UNC x 1/8 in
66	L005216	(5)	OS216	Pivot Screw
67	L005217	(5)	OS217	Pivot Screw
68	L005447	(10)	CS447,0550	Screw 1/4 in-20 UHF x 3/4 in
73	LOOU070	(10)	OU70	Spring
74	LOOU071	(10)	OU71	Spring
75	L00U072	(10)	OU72	Spring
80	L00W182	(10)	OW182	Bearing
81	LOCW024	(25)	CW24	Spring Dowel 1/8 in dia. x 5/8 in - top
82	L004024	(10)	OW24	Spiral Pin 3/32 in x 7/16 in
83	LOCW762	(25)	CW762,OW40	Spring Dowel 1/8 in dia. x 1/2 in - bottom



Index No.	Part No.	Equal to	Part	Serial No
1*	F14V3i,	15V-3	Forme Roller - complete with 2,, 16,60,69,70,81,82 and 86	
2	F14V315	19V-3	Spindle	
3	F14V060	181V	Locking Collar	
4*	F14V316	20V-3	Auxiliary Oscillating Roller - complete	
5*	F14V317	21V-3	Shaft	
6	F14V063	282V	Bearing	
7	F14V064	134V	Worm	
8	See 3,4 and 5 on H4		Carrier Plate - L.H.	
9	See 3,4 and 5 on H4		Carrier Plate - R.H.	
12	F14V069	140V	End Cap - L.H.	
15	F14V072	138V	Half Nut	
16*	F14V320		Forme Roller	
17	E14H269		Auxiliary Oscillating Roller Sub. Assembly with R.N. and L.H. End Caps	From 16D66


* 313 Parts

50	L00P023 (10)	0P23	Spring Clip
60	LOHS008 (10)	HS8	Screw M4 x 4mm
63	LOOS164 (10)	OS164	Screw 10-32 UNF x 1/8 in
64	L00S263 (10)	OS263	Screw
69	L00T028 (10)	0728	Nut 3/8 in-24 UNF
70	M14V006 (10)		Nut - L.H. 3/8 in-24 UNF
81	L00W014 (4)	0W14	Tolerance Ring
82	L00W022 (2)	0W22	Bearing
84	L00W032 (25)	0W32	Spring Dowel 3/32 in dia. x 7/16 in
86	LOHW207 (2)	HW207	Retaining Collar




Index Part No.	Equal to	Part	Serial NC
1 E14H182		Side Frame - L.H. - complete with 80,82,84,85,86,87,88,89,90 and 92	
2 F14V003	7V	Stud	
3 E14H183		Side Frame - R.H. - complete with 80,82,85,86,87,88,89, and 92	
4* E14H168	25V-3	Ink Fountain Roller Bearing - L.H.	
5* E14H170	26V-3	Ink Fountain Roller Bearing - R.H.	
6 F14V085	36V	Side Plate - bottom L.H. side	
7 F14V086	231V	Fixing Plate - top L.H. side	
8 F14V087	215V	Side Plate - bottom R.H. side	
9 F14V088	214V	Fixing Plate - top R.H. side	
10 F14S018	46S,185V	Adjusting Nut	
11* F14V321	22V-3	Ink Distributor Roller - complete with 12 and 79	
12* F14V322	23V-3	Gear (half drilled)	
13 F14V091	190V	Worm	
14 E14H055		Worm wheel	
15 F14V092	194V	Eccentric Shaft	
16 F14V093	197V	Connecting Rod	
17 F14V094	195V	Bracket	
18 F14V095	203V	Bracket	
19 F14V096	200V	Bell Crank	
20 F14V097	208V	Driving Roller	
21 F14U040	129U,205V	Ball Race	
22* E14H245		Main Oscillating Roller	
24 F141J037	135U	Guide wheel	
25* E14H198		Ink Unit - complete (not shown) comprising all parts shown on frames H2-H7	
26 E14H305		Gear	
27 E14H311		Main Oscillating Roller - only	

* 313 Parts



Index No.	Part 'o.	Equal to	Part	Serial No
50	LOC003 (25)	CR3	Lock Washer	
55	L00S178 (10)	OS178	Screw	8-32 UNC x 3/16 in
56	M14A009 (25)	OS10	Screw	10-32 UNF x 5/8 in
57	L00S013 (10)	OS13	Screw	10-32 UNF x 1 in
58	L00S014 (25)	OS14	Screw	10-24 UNC x 3/8 in
60	L00S017 (25)	OS17	Screw	10-24 UNC x 3/4 in
61	L00S447 (10)	C5447	Screw	1/4 in-28 UNF x 3/4 in
62	L00S166 (25)	OS166	Screw	10-32 UNF x 1/4 in
63	L00S386 (10)	C5386	Lock Screw	10-32 UNF x 1/8 in
64	L00S219 ()	OS219	Locking Screw	
65	L00S220 ()	OS220	Screw	
66	L00S399 (10)	CS399	Screw	10-32 UNF x 3/16 in
67	L00S034 (10)	OS34	Screw	1/4 in-20 UNC x 3/4 in
72	L001023 (10)	OT23	Nut	10-32 UNF
77	L00W004 (25)	OW4	Taper Pin	No.1 x 1.1/4 in
78	L00W017 ()	OW17	Pivot Pin	
79*	L00W026 (25)	OW26	Roll Dowel	3/32 in dia. x 11/16 in
80	L00W158 (10)	OW158	Bush	
81	L00W183 ()	OW183	Distance Collar	
82	L00W184 ()	OW184	Bearing	
83	L00W185 ()	OW185	Bush	
84	L00W047 (25)	OW47	Spring Dowel	5/32 in dia. x 1.3/4 in
85	L03W067 ()	OW67	Spring Peg	
86	L00W180 ()	OW180	Bush	
87	L00W044 (25)	OW44	Spring Dowel	5/32 in dia. x 3/4 in
88	L00W064 ()	OW64	Spring Peg	
89	L00W065 ()	OW65	Spring Peg	
90	L03W114 (10)	OW114	Spring Peg	
92	M14V002 ()	22V	Spring Peg	
93	L00W046 (25)	OW46	-Spring Dowel	5/32 in dia. x 1 in
94	L00W158 (10)	OW158	Bush (not shown)	

* 313 Parts






Index No.	Part No.	Equal to	Part	Serial No.
1	E14R298		Control Panel Assy.	
2	E14R297		Control Panel for 1	
3	F14W032		Mains On/Off Switch for 1	
4	E14R231		Harness for 3	
5	E14R186		P.C.B. for 1	
6*	E14N185		Back Plate for 7'	
7	E14N074		Support for 8 and 11	
8	E14N076		Back Support	
9	E14N069		L.H. Support for 8 and 11	
10	E14N068		R.H. Support for 8 and 11	
11	E14N077		Front Support	
12	E14R227		Ribbon Cable Assembly for 1 (20 way)	
13	E14R209		Bracket for 12 - complete with 75	
14	F14W026		Connector for 4 (4 way)	
15	E14R223		Microprocessor for 5	


From 15D368

* 313 Parts


51	LOOR025	(10)	OR25	Washer for 61
52	LOCR108	(10)	CR108	Washer for 63
61	LOOS004	(25)	OS4	Screw for 6 8-32 UNC x 1/2 in
62	M14W013	(10)		Screw (Taptite) 8-32 UNC x 3/8 in for 7
63	LOCS407	(10)	CS407	Screw for 7 8-32 UNC x 3/8 in
64	LOHS215	(10)	HS215	Screw for 8, 9, 10 and 11 8-32 UNC x 1/4 in
65	M14A007	(10)		Screw for 9 10-24 (INC x 1/2 in
66	LOOS020	(10)	OS20	Screw for 10 10-24 UNC x 1.1/2 in
70	LO1J016	(10)		Nut for 61 8-32 UNC
76	P14N072	(10)		Spacer for 9 and 10
77	LOCW877	(4)	CW877	Spacer for 10
78	LO5E290	(5)		On/Off Label (French)
79	P14R299	(4)		Support for 2
80	LOHW236	(4)	HW236	Tie for 12







Index No.	Part No.	Equal to	Part	Serial No.	Index No.	Part No.	Equal to	Part	Serial N
1	, 194		Lamp Unit complete - 200V ge		68	L0DT001	DT1	Nut for 55 6-32 UNC	
2	E14R200		Lamp Unit complete - 100V Range (UL and CSA)		69	LOHT009 (25)	HT9	Nut for 56 M4	
4	F14W008		2 Pin Connector for 1 and 2		70	LOHT019 (10)	HT19	Nut for 59 10-24 UNC	
5	F14W009		1 Pin Connector for 1 and 2		71	LOCT072 (10)	CT72	Nut for 58 4-40 UNC	
6	E14R224		Wiring Harness for 24 - complete with 7-15		74	LOHW186 (5)	HW186	Fuse for 29 2A 250V Quick Acting	
7	F14W010		Connector		75	LOHW387 (5)	HW387	Fuse for 29 7A Anti-surge	
8	F14W011	6876-S	Connector		77	M14W002 (-5)		Fuse for 15 15A 250V (HV 50 Hz)	
9	F14W012		Connector - 3 way		78	M14W003 (5)		Fuse for 16 Anti-surge 8A 250V and 7 (HV 50 Hz)	
10	F14W013		Connector - 3 way		79	10CW473 (2)	CW473	Clip for 19 and 20	
11	F14W014		Connector - 4 way		80	L05E337 (10)		Mains Fuse Label HV 50 Hz	
12	F14W015		Connector - 6 way Polarised		81	L05E338 (10)		Fuse Label (Drive NV 50 Hz Motor)	
13	F14W016	286161788P	Connector - 8 way		82	L05E339 (10)		Fuse Label (Vacuum NV 50 Hz Motor)	
14	F14W017		Block - 3 way		83	L05E340 (10)		Power P.C.B. Label	
15	F14W018	282160227P	Fuse Holder (Mains) 200V Range 50 Hz		84	L05E341 (10)		Mains Label	
16	E14R234		Fuse Holder (Vacuum Motor) 200V Range 50 Hz		85	LOHW388 (10)	HW388	Earth Label	
17	E14R233		Fuse Holder (Drive Motor) 200V Range 50 Hz		86	M14W007 (5)	3029WT	Label for 31	
18	F14W019		Connector - 6 way for 25 and 26		87	LOW104 (10)	HW104	Tie for 6	
19	E14R226		Mains Lead for 14 200V Range		88	L05E342 (10)		Lamp Rating Label for 1 and 2 (60 watts)	
20	E14R225		Mains Lead for 14 (CSA) 100V Range		90	M14W018 (10)		Terminal for 6,27 and 28	
21	F14A002		Strain Relief for 1,2,19 and 20		91	M14W027 (10)		Terminal for 27 and 28	
22	E14N114		Plate for 24		92	M14W028 (10)		Terminal for 10,11,12,13 and 18	
23	E14N113		Bracket for 24		93	M14W021 (10)		Pin for 9	
24	E14N118		Box		94	M14W022 (10)		Pin for 1 and 8	
25	E14R228		Transformer 200V Range 50/60 Hz		95	M14W023 (10)		Socket for 9	
26	E14R229		Transformer 100V Range 50/60 Hz (Csa and UL)		96	M14W024 (10)		Socket for 7 and 8	
27	F14W020		Relay (Drive and vacuum Motors) 100/200V Range 50/60 Hz		97	LOHW259 (10)	HW259	Boot for 91	
29	E14R185		P.C.B.		98	L0CW495 (25)	CW495	Boot for 89 and 90	
30	E06A258		Bridging wire for 14		99	M14W016 (10)		Eyelet for 6	
31	E14N117		Cover for 24		100	M14W030 (10)		Eyelet for 1	
32	E14N120		Insulation Panel		101	P14R262 (5)		Spacer for 29	
33	F14W031		Bracket Assembly for 1 and 2		102	M14W001 (10)		Support for 29	
51	LOCR153 (10)	CR153	Washer for 70		103	L0LW063 (10)	LW63	Sleeve for 6	
52	L0LR003 (25)	LR3	Washer for 71		104	M14W032 (10)		Sleeve for 6	
53	LOOR015 (10)	OR15	Washer for 68	4					
55	LOOS130 (5)	OS130	Screw for 101 6-32 UNC x 1 in						
56	M14W033 (10)		Screw for 24 M4 x 16mm (earth)						
57	L0CS379 (10)	CS379	Screw for 22, 8-32 UNC x 5/16 in and 24						
58	M14W006 (10)		Screw for 15, 4-40 UNC x 3/8 in 16 and 17						
59	LOOS120 (10)	OS120	Screw for 25 10-24 UNC x 3/8 in and 26						
60	M14W009 (10)		Screw for 23 1/4 in-20 UNC x 3/8 in						
62	M14W008 (10)		Screw for 14 8-32 UNC x 3/4 in						
64	M14W011 (10)		Screw for 24 M10 x 20mm						
65	LOOS115 (10)	OS115	Screw for 27 6-32 UNC x 3/8 in						



J6




Index No.	Part No.	Equal to	Part	Serial No.
1	E14R 230		Main Wiring Harness Asses bly - complete with 2-14 and 50-65	
2	F14W 023		Connector - 12 way	
3	F14W 024		Connector - 9 way	
4	F14W025		Connector - 6 way	
5	F14W026		Connector - 4 -way	
6	F14W027		Connector - 2 way	
7	F14W 028		Connector - 4 way	
8	F14W029		Connector - 1 way	
9	F14W012		Connector - 3 way	
10	F14W030		Connector - 4 way	
11	F14W008		Connector - 2 way	
12	F14A011		Microswitch (2 Sheet Door)	
13	F14A009		Microswitch (L.H. and R.H. Back Guard)	
14	E14R 231		Harness for On/Off Switch	
15	E14R 261		Support Bracket for 1	
50	LOH W 104 (10)	HW 104	Tie for 1	
51	M 14W 031 (10)		Earth Eyelet for 1	
52	M144 016 (10)		Earth Eyelet for 1	
53	LOH14023 (10)	HW 23	Terminal for 1 and 14	
54	M1414017 (10)		Terminal for 1	
55	M1414018 (10)		Terminal for 1	
56	141414019 (10)		Insert for 4	
57	M1414020 (10)		Tab for 1	
58	P11414021 (10)		Pin for 3	
59	M 14W 022 (10)		Pin for 2,3,5 and 6	
60	PI1414023 (10)		Socket for 6,7 and 8	
61	P11414024 (10)		Socket for 3,6,7,9 and 10	
62	P11414025 (10)		Sleeve for 52	
63	LOC 14495 (25)	C 14495	Boot for 54 and 55	
64	P1 13V006 (10)		Boot for 57	
65	LOH W 025 (10)	111425	Boot for 53	
66	PI1414034 (5)		Spacer for 15	
70	LOOS005 (10)	0S5	Screw for 15 8-32 UN C x 3/4 in	





CED




Index No.	Part No.	Equal to	Part	Serial
1	E10P030		Blank ind Roller Wash Dispense , -	
2	E10P029		Dispenser Tray	
3	F148012	38X	Screw for 2	
50	LOCR005 (25)	CR5	Lock Washer for 56	
51	LOOR003 (25)	OR3	Washer for 56	
56	LOCT060 (25)	CT60	Nut for 3 1/4 in UNF	
8	E10P033		Work Tray - 3 Tier - complete	
9	E10P034		Work Tray - 1 Tier - complete	
10	F148013	278	Rubber Mat (not shown)	
14	E14U017	1X-3	Anti-static Unit - complete with 15	
15	F148014	31X	Spring Peg for 14	
17	E148052		Straight Edge Tail Clamp	
19	E14E130	229G	Sucker for Items 15 and 16 on 85 and 35 on C5	
50	LOCS421 (10)	C5421	Screw for 1 6-32 UNC x 5/16 in	
51	L01A034 (10)		Screw for 1 8-32 UNC x 1/4 in	
56	L04A096 (10)		Spring for 1	
20	F148032	28V-3	Dust Cover for Ink Unit	
21	F14B344		Machine Dust Cover (not shown)	



Index No.	Part No.	Equal to	Part	Serial
1*	E14F068		Feedboard - complete (not shown)	
2	E14F032		Bracket	
3*	E05E464		Scale	
4*	E14F063		Feedboard	
5	E14F073		Spindle	
6	E14F029		Arm	
7	E14F031		Block	
8	E14F071		Lower Roller	
9	E01E068		Screw	
10	E14F055		Roller	
11	E14E145		Bar	
12	E01E070		Screw	
13	E14F054		Top Roller	
14	E01J021		Nut	
50	L0LP005 (10)	LP5	Spring Clip	
51	M14R004 (25)		Spring Clip	
55	LOC156 (10)	CR156,HR25	Washer	
56	LOC037 (25)	CR037	Washer	
57	M14F006 (25)		Washer	
60	M14F004 (25)		Screw	4-40 UNC x 3/8 in
61	L005168 (10)	0S168	Screw	10-32 UNF x 3/8 in
62	M14F005 (10)		Screw	10-24 UNC x 3/8 in
65	LOHT050 (10)	HT50,0T9	Nut	1/4 in-20 UNC
67	L04E075 (5)		Spring	
70	L035265 (5)		Pin	
* 313 Parts				



60 y" 2 & 3




Index No.	part No.	Equal to	Part	Serial N
1*	E14F067		Height Contr.:7,1 Bar	
2	E14F036		Guide Rail - R.H.	
3	E14F037		Guide Rail - L.H.	
4	See 84,5		Adjusting Screw	
5	E14F051		Block	
6	See 87,9		Roller	
7	E14F043		Stop	
8	E14F041		Plate	
9	E14F039		Chain	
10	E01E069		Stud	
50	LOCP006 (25)	CP6	Spring Clip	
51	M14F007 (25)		Spring Clip	
55	M14F006 (25)		Washer	
56	L02A025 (25)		Washer	
60	L00S120 (10)	0S120	Screw	10-24 UNC x 3/8 in
61	L00S036 (10)	0S36	Screw	1/4 in-20 UNC x 1 in
62			Screw	1/4 in-20 UNC x 1/2 in
65	LOHT050 (10)	HT50,019	Nut	1/4 in - 20 UNC
68	M14J005 (10)		Taper Pin	11/64 in dia. x 3/4 in
69	L14F040 (5)		Stud	

313 Part

L...

1,2,3,4&5



6


Index No.	Part No.	Equal to	Part	Serial N
1	1503		Allen Key - 3/32 in	
2	1504		Allen Key - 1/8 in	
3	1505		Allen Key - 5/32 in	
4	F14T029		Allen Key - 4mm	
5	T506		Allen Key - 3/36 in	
6	1513		Spanner - 3/8 in & 7/16 in	
7	7576		Setting Strips (Pack of 10)	
8	6X		Ink Knife	
9	E00H025		T. Bar - 5/32 in	
10	51X		Tool Pouch	




7




8



9



10




Index No.	Part No.	Equal to	Part
1	F14C001	103C	Base Board
2	E1,4006	9147006L99	Vacuum Pump
3	F14C002	95C	Adaptor
4	E147007	9141007G99	Pulley
5*	F14E012	4E-3	Motor 1/2 h.p. 100V/110V 50 Hz
6*	F14E013	6E-3	Motor 1/2 h.p. 200V/220V 60 Hz
7*	F14E014	9E-3	Motor 1/2 h.p. 220V/240V 50 Hz
8*	F14E015	10E-3	Motor 1/2 h.p. 100V 50 Hz/60 Hz
9*	E141043		Pulley 50 Hz
10*	E141044		Pulley 60 Hz
12*	F14C010	6C	'V' Belt (Motor to Pump) 50 Hz
13*	F14C014		'V' Belt (Motor to Pump) 60 Hz
15	F14C013	7C	Clamp
16*	E147065		Filter
17	F14C014	96C	Element
18	E147010	9147010G99	Sealing Washer
19	E147011	9147011C99	Stud
20	F14C015	16C	Coupling
21	F14C016	17C	Adaptor
22	E141014		Bracket
23	E141070		Air Valve Assembly
25	F147057		Valve Body
26	E147051		Vacuum Tee
27	F14C021	101C	Connector
28	F147059		Vacuum Valve Spindle
29	F14C025	102C	Air Hose 533mm (21 in)
30	F14C024	84C	Cover
31	F14E021	122W	Gland
32	E14R214		Lead for 5,6,7 and 37
33	E14R215		Lead 8 and 34
34*	F14E023	5E-3	Motor 1/2 h.p. 110/120V 60 Hz (CSA)
35	F14E026		Plug for 32 and 33
36	E14R259		Thermal Cut-out Harness (CSA & UL) for 34
37	F14E029		Motor 1/2 h.p. Dual voltage 50 Hz
40	F14C028		Adaptor
41	F14C030		Tee
42	F14C032		Adaptor
43	F14C031		Vacuum and Filter Tee
	E14E211		Paper Separator Blower (Centre) not shown see B5-42

* 313 Parts


67 74 81 79 60

""), frd




Index No.	Part No.	Equal to	Part
50	LOOR003	OR3	Washer
51	LOOR007 (25)	OR7	Washer
52	LOOR066 (25)	OR66	Lock Washer
53	P147012 (10)	9141012y99	Washer
54	LOCR005 (25)	CR5	Lock Washer
57	10H5175 (10)	H5175	Screw 1/4 in-28 UNF x 3/4 in
58	LOCS410 (10)	CS410	Screw 1/4 in-20 UNC x 3/8 in
59	L005033 (25)	OS33	Screw 1/4 in-20 UNC x 5/8 in
60	L005166 (25)	OS166	Screw 10-32 UNF x 1/4 in
61	100S257 (5)	05257	Bolt M8 x M25
62	M14C001 (5)	222765173P	Bolt M8 x M40
66	M14G006 (10)		Nut 1/4 in-28 UNF
67	LOOT006 (5)	076	Nut 5/8 in-18 UNF
68	LOHT006 (10)	0137,1416	Nut M8
69	P147009 (10)	914701091'99	Nut 2 BA
74	100U093 (5)	OU93	Spring
79	L00W021 (2)	OW21	Knob
80	L00W055 (5)	OW55	Wing Nut 1/4-20 UNC
81	L004197 (5)	OW197	Collar
82	L02J129 (5)		Spacer
83	LOHW104 (10)	HW104	Tie for 36
84	M14W016 (10)		Eyelet for 32,33 and 36
85	M14W017 (10)		Terminal for 36
86	M14W020 (10)		Tab for 36
87	M13V006 (10)		Boot for 86
88	10CW495 (25)	CW495	Boot for 85
89	LOHW410 (5)	HW410	Clamp

L2



Index No.	Part No.	Equal to	Part	Serial No.
1	E14R218		Solenoid 22-29V	16D581
2	E147021		Shaft	
3	E141019		Manifold	
4	E141015		Vacuum Shut-off Assembly	
5	E141063		3-way valve for vacuum Pipe	
6	E141017		Bracket	
7	E141032		Air Pipe from 3 to Pressure Filter Tee	
8	E141035		Air Pipe from 3 to 14	49 in
9	E141033		Left and Right Blower Pipe	16 in
10	E141034		Centre Blower Pipe	10 in
11	E141030		Vacuum Pipe for 5 and 13	13.1/4 in
12	E141047		Vacuum Pipe from filter to Vacuum Tee	14.1/2 in
13	F1411004	5611	Connecting Tube	
14	E141053		Spray Tube	
15	E141062		Connecting Tube	
16	E141023		Elbow	
17	E141045		By-pass Pipe	11 in
18	E141046		Pipe 1" Piece to 3-way Valve	13 in
19	E14T048		Pipe 1" Piece to Control Valve	9.1/2 in
20	F14C312		Tee Hose Connector	
21*	F14C310	4C-3	Left and Right Blower Tube	
22*	F14C305	3C-3	Hose for 26	
23*	F14C307	8C-3	Bracket for 26	
24*	F14C308	9C-3	Retaining Plate for 23	
25*	F14C306	7C-3	Retaining Clip for 22	
26*	F14C309	10C-3	Side Blower	
27*	E141069		Air Pipe from 3 to Air Coupling 26 in	
* 313 Parts				
50	LOOP002 (25)	OP2	Spring Clip	
51	L0LP003 (25)	LP3	Spring Clip	
52	LOCPO09 (25)	CP9	Spring Clip	
55	LOCRO79 (10)	CR79	Lock Washer	
56	LOOR014 (25)	OR14	Washer	
57	LOOR003 (25)	OR3	Washer	
58	M14A011 (25)		Lock Washer	
59	LOOR067 (25)	OR67	Lock Washer	
60	LOCRO58 (25)	CR58	Washer (plastic)	
61	LOOR066 (25)	OR66	Lock Washer	
62	LOCRO71 (10)	CR71	Washer	
65	LOOS003 (10)	OS3	Screw 8-32 UNC x 3/8 in	
66	M14F003 (10)		Screw 8-32 UNC x 1.1/4 in	
67	LOOS036 (10)	OS36	Screw 1/4 in-20 UNC x 1 in	
68	M14F002 (10)		Screw 3/8 in-16 UNC x 1.1/4 in	
69	LOOS098 (10)	OS98	Screw 8-32 UNC x 5/8 in	
70	LOOS032 (25)	OS32	Screw 1/4 in-20 UNC x 1/2 in	
71	LOOS009 (25)	OS9	Screw 10-32 UHF x 1/2 in	
74	LOO1017 (10)	O117	Nut 3/8 in-16 UNC	
79	LO4A149 (10)		Spring	
84	LO35211 (5)		Peg	
85	P141022 (5)		Piston	
86	LO2J131 (5)		Spacer	
87	LO1W072 (3)	OW72	Clamp	
88	M14C002 (5)		Clamp	
90	LOOW188 (10)	OW188	Clip	
91	LO3W081 (5)		spring Peg	
92	LOHW145 (4)	MW145	Pad	
93	LOHN410 (5)	HW410	Clamp	
94	M14C004 (10)		Edge Clip	
95	M14C003 (3)		Clamp	


L3



Index No.	Part No.	Equal to	Part	Serial
1	F14G091	1076	Swivel Bracket	
2	F14G092	12443	Screw	
3*	F14G313	226-3	Lifting Shaft	
4	F14G094	122G	Blower - R.H.	
5	F14G095	1196	Bracket - R.H. - not for Magazine Feed	
6	F1443096	132G	Blower - L.H.	
7	F14G097	1286	Bracket - L.H. - not for Magazine Feed	
8	F14G098	1336	Back Weight	
9*	F146314	23G-3	Shaft	
10	F14G100	2256	Side Arm - L.H. - complete with 60 and 77	
11	F146101	2266	Side Arm - R.H. - complete with 60 and 77	
12	F146102	30%	Side Fence	
13	E14F034		Feedboard Guide - L.H. and R.H.	
14	E14F053		Bracket - L.H. (not shown)	
15	E14F052		Bracket - R.H.	
16	E14F035		Support	
17*	E14E214		Feed Guide - L.H.	From 16E1.1
18*	E14E213		Feed Guide - R.H.	
19	See 87-9			


* 313 Parts

50	LOCP008	(25)	CP8	Spring Clip
56	M146002	(25)	OS16	Screw
57	M14J007	(10)		Screw
59	L00S017	(25)	OS17	Screw
60	L00S024	(25)	OS24	Screw
61	M1443007	(10)		Screw
63	L00S199	(5)	OS199	Screw
64	L00S255	(10)	OS255	Screw
66	L00S200	(5)	OS200	Screw
68	L00T010	(5)	07010	Nut
74	LOCW562	(10)	CW562	Spring Dowel
76	L00W080	(5)	OW80	Spring Plate
77	L00W082	(5)	OW82	Eccentric Nut
78	L00W083	(10)	OW83	Plate




Index No.	Part No.	Equal to	Part	Serial
1*	E14V041		Platform	
2*	F14S301	2S-3	Front Roller	
3	F14S002	3S	Cover	
4	F14S003	4S	Bearing	
5*	F14S302	3S-3	Ball Carrier	
6*	F14S303	4S-3	Belt (set of 3)	
7*	E14V083		Side Guide	From 14..
8*	F14S304	5S-3	Retainer	
9*	E05E299		Scale	
10*	F14S306	7S-3	Shaft	
11*	F14S307	8S-3	Tie Rod	
12	F14S010	23S	Adjusting Shaft	
13	F14S011	33S	Chain - 72 Links	
14	F14S012	34S	Chain - 61 Links	
15*	F14S308	10S-3	Back Roller	
16	F14S014	37S	Bearing Bracket - L.H.	
17	F14S015	38S	Bearing	
18	F14S016	39S	Bearing Bracket - R.H.	
19	F14S017	45S	Drive Gear	
20	F14S018	46S, 185V	Adjusting Nut	
21	F14S019	49S	Gear/Sprocket Unit	
22	F14S020	50S	Gear/Sprocket Unit	
23	E14V019		Belt and Guide Adjusting Knob for L.H. side - complete with 64 on G1	
24	E14V028		Belt and Guide Adjusting Knob for R.H. side - complete with 64 and 79 on G1	
25*	F14S309	37-3	Adjusting Screw - L.H. side	
26*	F14S310	51-3	Adjusting Screw - R.H. side	
27*	F14S311	61-3	Scissor Bracket	
28*	F14S312	41-3	Shaft	
29	F14S027	541	Bearing	
30	F14S028	521	Sprocket	
31*	E14V081		Support Bar	
32*	E14V082		Centre Guide	From 16D6i
33*	E14V084		Bracket	
73*	LOOS009	(25) 0S9	Screw	10-32 UNF x 1/2 in
* 313 Parts				

PLEASE NOTE: FOR THE UNIT PACKS SEE G1




Index No.	Part No.	Equal to	Part	Serial
1*	E14V099		Jogger Side Guide - L.H.)	
2*	E14V098		Jogger Side Guide - R.H.)	
3	F147001	97	Adjusting Knob	From 16D
4*	E14V104		Feather	From 16D
5	E14V003	13T	Stud	
6*	F147105		Feather	From 160
7	F147028		Bracket	
8*	F147301	17-3	Adjusting Screw R.H. -	
			complete with 7, A & B	
9*	F147302	27-3	Adjusting Screw L.H. -	
			complete with 7, A & B	
10	F147008	237	Plate	
12	F147010	361	Bracket	
13	F147011	297	Lever	
14	F147012	337	Spring Plate	
15	F147013	357	Yoke	
16	F147014	48T	Plate	
17	E14V005	46T	Lever - R.H.	
18	F147015	40T	Push Rod	
19	E14V004	477	Lever - L.H.	
20	F147025	621	Adjusting Bracket	
21	F147026	661	Tension Weight	
22	F147027	737	Bracket - L.H. and R.H.	
23*	E14V085		Slide Block	
24*	E14V093		Pivot Block	
25*	E14V095		Bracket - L.H.)	From 16D
26*	E14V094		Bracket - R.H.)	
* 313 Parts				




Index No.	Part No.	Equal to	Part	Serial
50	LOOP001	OP1	Spring Clip	
51	LOLP003 (25)	LP3	Spring Clip	
52	LOOP010 (25)	OP10	Spring Clip	
53	LOOP005 (25)	OP5,LP5	Spring Clip	
57	LOOR022 (10)	OR22	Washer	
58	LOOR014 (25)	OR14	Washer	
59	LOOR025 (10)	OR25	Washer	
60	LOOR026 (10)	OR26	Washer	
61	LOOR031 (10)	OR31	Washer	
62	LOOR075 (10)	OR75	Shim Washer	
63	LOOR003 (25)	OR3	Washer	
64	LOCRI53 (10)	CR156,OR21	Washer	
65	LOCRI45 (25)	CR145	Lock Washer	
66	LOOR001 (25)	OR1	Washer	
67	M14V003 (10)		Shim Washer	
70	LOC5386 (10)	CS386	Screw	10-32 UNF x 1/8 in
71	LOOS002 (25)	OS2	Screw - R.H.	8-32 UNC x 1/4 in
72	LOOS100 ()	OS100	Screw	10-32 UNF x 1.1/4 in
73*	M147001 (10)		Screw	8-32 UNC x 3/32 in
74	LOOS103 (10)	OS103	Screw	8-32 UNC x 3/8 in
75	LOOS104 (10)	OO04	Screw	8-32 UNC x 3/16 in
76	LOOS105 (10)	OS105	Screw	10-24 UNC x 3/8 in
77	LOOS176 (10)	OS176	Screw	8-32 UNC x 1/8 in
78	LOOS064 (10)	OS64	Screw	1/4 in-28 UNF x 5/8 in
79	LOOS004 (25)	OS4	Screw - L.H.	8-32 UNC x 1/2 in
80	LOOS169 (10)	OS169	Screw	113-32 UNF x 1/2 in
81*	LOOS177 (10)	OS177	Screw	8-32 UNC x 3/16 in
82	M14M008 (10)		Nut	8-32 UNC
83	LOO7032 (10)		Nut	6-40 UNF
84	M14G006 (10)		Nut	1/4 in - 28 UNF
90	LOCU048 (10)	OU48	Spring	
91	LOOU049 (10)	OU49	Spring	
92	LOOU050 ()	O(150	Spring	
93	LOOU051 ()	O(151	Spring	
94	LOOU052 ()	O052	Spring	
100	LOOW045 (25)	OW45	Spring Dowel	5/32 in x 7/8 in
101	LOCW033 (25)	OW33	Spring Dowel	3/32 in dia. x 3/4 in
102	LOOW085 (10)	OW85	Plug	
103	LOCW146 (20)	OW146	Spacer	
104	LOOW148 ()	OW148	Stop - L.H.	
105	LOOW149 ()	OW149	Collar	
106	LOOW150 (20)	OW150	Steel Ball	
107	P14V017 ()		Bracket - old-style (Oyster)	
108	P14V018 ()		Bracket - old-style (Blue Black)	
109	LOO4153 ()	OW153	Sleeve	
110	LOOW154 ()	OW154	Bracket	
111	LOOW155 ()	OW155	Roller	
112	LOOW156 ()	OW156	Spindle	
113	LOCW217 ()	OW217	Spindle	
114	LOOW147 ()	OW147	Cap - R.H.	
115	LO1J016 ()		Nut	8-32 UNC x 5/8 in
116*	M14V101 ()		Bracket (Oyster)	
117*	M14V100 ()		Bracket (Blue Black)	
118*	P14V088 ()		Knob	
119*	P14V089 ()		Brush	

* 313 Parts

From 16Do






Index Part No	Part No	Equal to	3	No.
1	E14X168			Bottle Complete with 1,2,3,4,50 & 60
2	E14X162			Bottle
3	F14U050	187U		Cap
4	F14U051	188U		Insert
5	F14U052	182U		Valve
6	E1 4X160			Bottle Holder with 70
7	E14X159			Bracket
8	E14X161			liase
9	E14X163			Trough
10	E14X156			RH Side Frame
11	E14X157			LH Side Frame
12	14N305			Printer Cover Upper RH see 313 Fiche index 2, A2
13	E1 4X173			Water Stop Shaft
14	E14X171			Water Stop Shaft
15	E1 4X177			Water Stop Kit - Complete with 13, 71 and fitting instructions.
50	LOOP019 (25)	0P19		Spring Clip
59	LOOR020 (10)	0R20		Spring Washer
60	L001R027 (10)	0R27		Washer
64	LOOS017 (10)	0317		Screw 10-24 UNC x3/4 in long
65	P14X167 (10)			Screw
68	L001023 (10)	0123		Nut 10-32 UNF
70	M14U015(4)			Connector
71	P14X174 (10)			Water Slop




ATTACHMENTS

INDEX


Chain Pile Delivery Unit	A1, A2, A3
Conveyor	A4
Delivery Tray Frame and Collecting	
Board	A5
Guards	A5
Side Plates and Base	A6
Drive Assembly	A7
Handwheel	B1
Light Unit	B2
Anti-Set-Off Spray	C2, C3
Automatic Ink Roller Cleaning	C4
4 Sucker System	C5
Blanket Cleaning Attachment	E1, E2, E3, E4
Manual Plate Loading Platform	F1, F2




Index No.	Part No.	Equal to	Part	Serial No.
1	E10A441		Chain Pile Delivery Unit HV - complete (not shown)	
2	E10A406		L.H. Side Frame	
3	E10A405		R.H. Side Frame	
4	E10A259	504C-3	Adjusting Nut for 2 and 3	
5	E10A110	107CP	Spacer for 2 and 3	
6	E10A273	506C-3	Support Plug for 2 and 3	
7	E10A175	509C-3	Front Tie Bar for 2 and 3	
8	E10A150	512C-3	Back Tie Bar (Top) for 2 and 3	
9	E10A148	513C-3	Back Tie Bar (Bottom) for 2 and 3	
10	E10A372		Lower Chain Guard Rail Support - L.H. for 2	
11	E10A371		Lower Chain Guard Rail Support - R.H. for 3	
12	E10A104	170CP	Adjusting Screw for 10 and 11	
13	E10A214	511C-3	Pick-up Cam	
14	E10A266	105CP	Back Stop Tie Bar	
15	E10A151	698C-3	Back Sprocket Shaft - complete with 16,17,18,64,79 and 80	
16	E10A156	542C-3	Cam for 15	
17	E10A153	106CP,537C-3	Sprocket - complete with 80	
18	E10A155	539C-3	Adaptor for 15 (R.H. End)	
19	E10A274	546C-3	Adjusting Nut for 20	
20	F14P019	544C-3	Adjusting Screw for 18	
21	F14P020	547C-3	Spring for 20	
22	E10A215	696C-3	Back Stop Block	
23	E10A002	697C-3	Back Stop Stripper for 22	
24	E10A125	108CP	Back Stop Blade	
25	E035197	109CP	Pivot Pin for 24	
26	E10A373		Guard for 15	
27	F14P031	627C-3	Spacer for 26	
28	E10F055		Blanket Wash Tube	
29	E14R235		Blanket Wash Harness	
30	E10A442		Chain Pile Delivery Unit (LV and CSA) - complete (not shown)	




Index Part No.	Equal to	Part	Serial No.
50	LOOP006 (25) 0P6	Spring Clip for 25	
54	LOCR110 (25) CR110,0R60	Lock Washer for 61	
55	P14A394 (10)	Washer for 70	
56	LOHR101 (10) HR101	Washer for 6	
57	L00R007 (25) 0R7	Washer for 20	
58	LOCR017 (25) CR17	Washer for 68	
59	L02A079 (10)	Washer for 60	
60	M14P013 (5)	Screw for 85 1/4 in-20 UNC x 2.1/4 in	
61	L00S038 (10) 0538	Screw for 26 1/4 in-20 UNC x 1.1/2 in	
62	LOHS150 (25) HS150	Screw for 23 4-40 UNC x 1/4 in	
63	LOHS151 (10) HS151	Screw for 22 5/16 in-18 UNC x 3/4 in	
64	L005390 (10) HS182,C-5590	Screw for 16 1/4 in-28 UNF x 1/4 in	
65	L005014 (25) 0S14	Screw for 56 10-24 UNC x 3/8 in	
66	L00S036 (10) 0S36	Screw for 4 1/4 in-20 UNC x and 5 1.1/4 in	
67	L005051 (10) 0S51	Screw for 7, 1/4 in-28 UNF x 7/8 in 8,9,13 and 14	
68	L005097 (25) 0S97	Screw for 10 10-24 UNC x 1/2 in and 11	
69	LOHS166 (10) H5166	Screw for 10 10-24 UNC x 3/4 in and 11	
70	LOOT008 (25) OT8	Nut for 61 1/4 in-20 UNC	
73	LOHU100 (4) HU100	Spring - L.H. for 24	
74	LOHU101 (4) HU101	Spring - R.H. for 24	
79	LOCW033 (25) HW30I,CW33	Spring Dowel 1/8 in x 1 in for 15	
80	LOHW303 (2) HW303	Bearing for 17	
81	LOCW035 (10) HW319,CW35	Spring Dowel 3/32 in x 3/8 in for 22	
82	LOHW323 (2) HW323	Bearing for 2 and 3	
83	LOHW315 (4) HW315	Grommet for 3	
84	PI0A374 (3)	Plug for 3	
85	PI0F092 (5)	Spacer for 3 when fitting Blanket Wash	











Index No.	Part No.	Equal to	Part	Serial No.
1	E10A157		Front Sprocket Shaft - complete	
2	F14P021	526C-3	Bearing for 1	
3	F14P042	527C-3	Drive Gear for 1	
4	E10A162	532C-3	L.H. Paper Guide Wheel	
5	E10A164	533C-3	R.H. Paper Guide Wheel	
6	E10A086	116CP	Jogger Side Guide - L.H.	
7	E10A208	117CP	Knob for 6 and 8	
8	E10A088	115CP	Jogger Side Guide - R.H.	
9	E10A221	699C-3	Jogger Shaft - R.H.	
10	F14P023	119CP	Jogger Bell Crank Assembly - complete with 11	
11	E10A419		Cover for 10	
12	E10A067	120CP	Connecting Link for 10	
13	F14P024	121CP --	Pin for 12	
14	E10A212	700C-3	Link Arm Shaft - complete	
15	E01E041	123CP	Pivot Screw for 14	
16	E10A091		Drive Link Arm for 14	
50	LOOP001 (25)	OP1	Spring Clip for 13	
51	LOOP002 (25)	OP2	Spring Clip for 9	
52	LOOP005 (25)	OP5	Spring Clip for 14	
57	LOCR134 (25)	HR103,CR134	Spring Washer for 64	
58	LOCR043 (25)	CR43,HR108	Washer for 64	
63	LOH5152 (10)	HS152	Set Screw for 1 10-24 UNC x 1/2 in	
64	LOHS153 (5)	HS153	Screw for 3 1/4 in-20 UNC x 1 in	
65	LOH5154 (10)	HS154	Set Screw for 4 and 5 1/4 in-20 UNC x 3/8 in	
66	LOHS183 (5)	HS183	Screw for 10 10-24 UNC x 1 in	
67	LOH5184 (10)	HS184	Screw for 16 1/4 in-28 UNF x 3/8 in	
68	MI4G002 (25)	0516	Screw for 10 10-24 UNC x 5/8 in	
72	LOHU107 (2)	HU107	Spring for 9	
77	LOHW302 (5)	HW302	Taper Pin for 1 0.187 in x 1.3/4 in	
78	LOHW322 (10)	HW322	Plug for 7	
79	LOHW010 (25)	HWIO	Spriol Pin for 14 5/32 in x 1 in	




Index No.	Part No.	Equal to	Part	Serial No.
1	E10A323	548C-3	Conveyor Chain - complete with 87 and 88	
2	E10A298	551C-3	Chain Guide	
3	E10A166	555C-3	Gripper Bar Assembly	
4	E10A167	557C-3	Gripper Bar - complete with 86	
5	F14P025	567C-3	Adjusting Collar for 81	
6	F14P043	559C-3	Shaft Assembly for 4	
7	E10A031		Gripper - complete with 66,70,89 and 90	
8	E10A173	717C-3	Operating Lever	
9	E10A203	594C-3	Jogger Adjusting Shaft	
10	E10A113	129CP	Front Jogger Blade for 9	
11	E10A204	587C-3	Jogger Link Cross Bar for 9	
12	E10A207	593C-3	Locking Knob for 11	
13	E10A123	128CP	Back Jogger Link for 11	
50	LOOP003 (25)	OP3	Spring Clip for 6	
51	LOOP005 (25)	OP5	Spring Clip for 13	
56	LOCR081 (25)	CR81	Spacer for 2 (R.H. Side)	
57	LOHR104 (10)	HR104	Spacer for 2 (L.H. Side)	
58	LOCR017 (25)	CR17,HR109	Washer for 69	
63	LOHS091 (5)	HS91,H5155	Screw for 10 1/4 in-20 UNC x 3/8 in	
64	LOHS156 (10)	H5156	Screw for 2 10-32 UNF x 5/8 in	
65	LOHS157 (25)	H5157	Screw for 5 10-32 UNF x 3/16 in	
66	LOLS074 (10)	LS74	Screw for 89 M3 x 6mm long and 90	
67	LOH5159 (2)	H5159	Screw for 92	
68	LOHS176 (25)	H5176	Screw for 4 8-32 UNC x 1/2 in	
69	LOHS185 (25)	H5185	Screw for 13 10-32 UNF x 5/16 in	
70	LOCS420 (10)	C5420	Screw for 7 8-32 UNC x 5/8 in and 8	
71	L005189 (10)	OS189	Lock Screw 1/4 in-20 UNC x 1/8 in for 63	
76	LOHT051 (10)	HT51	Nut for 67	
81	LOHU124 (10)	HU124	Spring for 4	
86	LOHW300 (2)	HW300	Bearing for 4	
87	LOHW304 (4)	HW304	Connecting Link for 1	
88	LOHW305 (4)	HW305	Support Link for 1	
89	LOHW306 (10)	HW306	Gripper Spring for 7	
90	LOHW307 (10)	HW307	Clamp for 89	
91	LOHW308 (10)	HW308	Spring Dowel for 6	
92	LOHW309 (2)	HW309	Roller for 8	




Index No.	Part No.	Equal to	Part	Serial No.
1	E10A369		Delivery Tray Frame	
2	E01J015	134CP	Stop for 1 (Top) - L.H.	
3	E013014	135CP	Stop for 1 (Top) - R.H.	
4	E10A216	702C-3	Collecting Board - complete	
5	E10A217	703C-3	Collecting Board for 4	
6	E10A082	132CP	Pull Rod for 4	
7	F14P027		Fixed Castor for 5	
8	F14P028		Swivel Castor for 5	
50	LOOR003 (25)	OR3	Washer for 58	
56	LOHS160 (5)	HS160	Screw Eye for 5	
57	LOHS186 (5)	HS186	Wood Screw No.12 x 5/8 in for 7 and 8	
58	L00S033 (25)	OS33	Screw for 2 1/4 in-20 UNC x 5/8 in and 3	
63	LOHW320 (2)	HW320	Roller for 1	
GUARDS				
12	E10A414		Top Guard - complete with 13,68,69, 78,79,85 and 90	
13	E10A397		Bracket for 12	
14	F14A008		Microswitch for 12	
15	E14R182		Bracket for 14	
16	F14G032	275G	Collar for 12 and 80	
17	E14N099		Back Guard	
68	LOCRO98 (10)	CR98	Washer for 85	
69	LOCRO17 (25)	CR17,HR109	Washer for 79	
70	L0LR008 (25)	LR8	Washer for 86	
71	LOCRO66 (25)	CR66	Washer for 77	
72	LOHW122 (4)	HW122	Washer for 93	
77	LOHS173 (10)	H5173	Screw for 15 10-32 UNF x 3/8 in	
78	M14P012 (10)		Screw for 13 10-32 UNF x 3/8 in	
79	L005058 (25)	C558	Screw for 90 2 BA x 7/16 in	
80	LOHS178 (10)	HS178,C5334	Screw for 12 10-32 UNF x 1/2 in	
85	LODT003 (25)	DT3	Nut for 78 10-32 UNF	
86	LOCT072 (10)	C172	Nut for 15 4-40 UNC	
90	LOCW384 (4)	CW384	Knob for 12	
91	L02A085 (10)		Spacer for 14 and 15	
92	LOHU004 (4)	HU4	Spring for 93	
93	M14A004 (4)		Lock Stud for 17	
94	LOHW117 (4)	HW117	Lock Cap for 93	
95	L05E279 (10)		Label for 17 (old-style not shown)	
96	L05E417 (10)		Label for 17	



Index No.	Part No.	Equal to	Part	Serial No.
1	E10A346		Side Plate - L.H.	
2	E10A365		Side Plate - R.H.	
3	E10A105	139CP	Adjusting Nut for 1 and 2	
4	E10A367		Base for 1 and 2	
5	E14R263		Cut-Off Microswitch	
6	F14P029	708C-3,511C-S 3660,5058	Cover for 5	
7	E14R232		Harness - L.H. for 5 and E14R218	
8	F14P030	710C-3	Bush for 7	
9	E10A348		Cover - L.H. for 1	
10	E10A363		Cover - R.H. for 2	
11	E10A101	142CP	Bracket for 5	
12	E14L020		Bracket for 2,13 and E14R218	
13	F143006		Push Button for 12	
14	F14.1007		Feed On-Off Microswitch for 13	
15	E14N182		Rear Cover for 313 Base (Collecting End)	
50	LOCRO05 (25)	HR105,CR5	Washer for 60	
51	LOCRO07 (25)	HR106,CR7	Lock Washer for 68	
52	LOOR015 (10)	OR15	Washer for 68	
53	LOCRO153 (10)	CR153,OR21	Washer for 58,59 and 63	
57	LOHS162 (10)	HS162	Screw for 5 6-32 UNC x 1.1/4 in	
58	L005009 (25)	059	Screw for 9 10-32 UNF x 1/2 in and 10	
59	L00S014 (25)	0S14	Screw for 4 10-24 UNC x 3/8 in	
60	L005038 (10)	0538	Screw for 1, 1/4 in-20 UNC x 2 and 3 1.1/2 in	
62	L00S099 (25)	0S99	Screw for 73 10-24 UNC x 1/4 in	
63	M143007 (10)		Screw for 12 10-32 UNF x 7/16 in	
64	L0H5231 (10)	H5231	Screw for 15 M4 x 16mm	
67	LOOT008 (25)	OT8	Nut for 60 1/4 in - 20 UNC	
68	LOOT030 (10)	OT30	Nut for 57 6-32 UNC	
73	L00W188 (10)	OW188	Clip for 7	
74	L05E303 (10)		Label for 9	
75	M14W017 (10)		Terminal for 7	
76	M14W020 (10)		Tab for 7	
77	M13V006 (10)		Insulating Boot for 7	
78	L0CW495 (25)	CW495	Insulating Boot for 7	
79	P10A262 (5)		Grommet for 10	
80	LOHWO93 (10)	HW93	Retainer for 7	
81	LOCW805 (10)	CW805	Tie for 7	




Index No.	Part No.	Equal to	Part	Serial No.
1	E10A199	711C-3	Drive Shaft Assembly	
2	E10A318	712C-3	Chain for 1	
3	F14G058	144CP,70G	Roller for 2	
4	E10A081	145CP	Worm Drive Assembly	
5	E10A064	146CP	Hand Drive Gear Shaft Assembly for 4	
6	E10A116	147CP	Collar for 5	
7	E10A059	148CP	Intermediate Gear for 5	
8	E10A077	149CP	Ratchet Shaft Assembly	
9	E10A085	154CP	Pile Drop Control Cam for 8	
10	E10A119	150CP	Ratchet Pawl Arm for 8	
11	E10A131	151CP	Pawl for 10	
12	E10A403		Link for 11	
13	E10A402		Link Extension for 12 and 14	
14	E14R196		-- Feed Shut-off Solenoid	
15	E10A103	158CP	Link for 10 and 16	
16	E10A074	155CP	Drive Link	
17	E10A095	156CP	Link Arm Extension for 16	
18	E10A120	157CP	Link for 16	
19	E10A313		Pile Drop Control Knob	
50	LOCP005 (25) CP5,HP6		Spring Clip for 15	
51	LOOP003 (25) OP3		Spring Clip for 65	
52	LOOP006 (25) OP6		Spring Clip for 10 and 18	
53	LOCP009 (25) CP9		Spring Clip for 92	
57	LOCR153 (10) CR153		Washer for 74	
58	LOOR003 (25) OR3		Washer for 10,76 and 66	
59	LOOR080 (10) OR80		Spring Washer for 75	
64	LOHS163 (2) HS163		Stud for 3	
65	LOHS164 (2) HS164		Stud for 7	
66	LOHS165 (10) HS165		Screw for 17 1/4 in-28 UNF x 5/8 in	
67	L005033 (25) 0533		Screw for 4 1/4 in-20 UNC x 5/8 in	
68	L005162 (25) 05162		Screw for 19 1/4 in-28 UNF x 3/8 in	
69	L005170 (10) 05170		Screw for 6 1/4 in-20 UNC x 1/4 in	
70	LOCS419 (25) CS419		Screw for 14 6-32 UNC x 1/4 in	
71	PI0A404 (5)		Screw for 12 and 13	
74	L001023 (10) 0123		Nut for 71 10-32 UNF	
75	LOHT054 (10) HT54		Nut for 65 5/16 in - 18 UNC	
76	LOHT055 (10) HT55		Nut for 64	
77	M14R002 (25)		Nut for 70 6-32 UNC	
82	LOHU106 (5) HU106		Spring for 10 and 15	
83	L04A032 (10) CU27		Spring for 12 and 71	
87	LOHW010 (10) HW10		Spring Dowel 5/32 in x 1 in for 1	
88	LOHW310 (2) HW310		Spacer for 1	
89	L00W044 (25) 0W44		Spring Dowel 5/32 in x 3/4 in for 1	
90	LOHW011 (25) HW11		Spirol Pin 1/8 in x 5/8 in for 8	
91	L05E329 (5)		Label for 19	
92	L035211 (5)		Peg for 13 and 14	




Index No.	Part No.	Equal to	Part
1	E10A083	160CP	Support Plate
2	E10A093	161CP	Plate Block (bottom) - L.H. for 1
3	E10A092	162CP	Plate Block (bottom) R.H. for 1
4	E10A370		Cut-out Lever for 2
5	E10A132	164CP	Ratchet Pawl Lock
6	E10A100	165CP	Stud for 5
7	E10A070	166CP	Rate Control Pin Block - complete with 51,75 and 77
8	E10A396		Handwheel with 9 and 63
9	E05E302		Label for 8
10	E14L023		Handle for 8
50	LOOP006 (25)	OP6	Spring Clip for 5 and 70
51	M14P006 (5)		Spring Clip for 77
56	P14L024 (10)		Cap Washer for 60
57	LOCR110 (25)	CR110,0R60	Lock Washer for 67
60	M14G001 (10)		Screw for 10 10-32 UNF x 1/2 in
61	L005033 (25)	OS33	Screw for 1,2 and 3
62	L005038 (10)	OS38	Screw for 1 1/4 in-20 UNC x 1.1/2 in
63	M14P015 (10)		Screw for 8 3/8 in-16 UNC x 1/2 in
67	LOOT008 (25)	018	Nut for 6 1/4 in-20 UNC and 62
70	LOHU102 (5)	HU102	Spring for 5
75	L00U0514 (10)	OU54	Spring for 77
76	LOCW024 (25)	HW311,CW24	Spring Dowel 1/8 in x 5/8 in for 1
77	L00W162 (5)	OW162	Plunger for 7


Serial No




Index Part No.	Equal to	Part	Serial No.
3 EI0A388		L.gnt Unit (HV)	
4 EI0A390		Light Unit (LV and CSA)	
5 FI4P032	ZA172,642C-3	Tube Holder for 3 and 4	
6 FI4P033		Starter Holder for 4	
7 FI4P034		Starter Holder for 3	
8 FI4P035	ZA 164,644C-3	Starter for 3'	
9 FI4P036	1021WT	Starter for 4	
10 FI4P037	655C-3	Choke for 3	
11 FI4P038	ZA152,1055WT	Choke for 4	
12 FI4P039	3S424E,1003WT	Block - 2 way for 3 and 4	
13 EI4R222		Harness R.H. for 3,4,E14R263 and FI4A008	
14 FI4W008		2 Pin Connector for 13	
15 FI4P040		Connector - 4 way for 13	
50 LOCR140 (25) CR140		Washer for 68	
51 LOCR007 (25) CR7		Washer for 69	
52 LOCR110 (25) CR110		Washer for 70	
53 LOCR153 (10) CR153		Washer for 56	
56 LOHS177 (10) HS177		Screw for 10 10-24 UNC x 1/4 in	
57 LOHS169 (10) HS169		Fixing Screw 10-32 UNF for 3 and 4 (L.H.)	
58 LOOS008 (25) 058		Fixing Screw 10-32 UNF x 3/8 in for 3 and 4 (R.H.)	
59 LOHS170 (25) HS170		Base Plate	
60 LODS019 (10) 0519		Screw for 5 6-32 UNC x 3/16 in	
61 LOCS171 (10) CS171		Screw for 12 4-40 UNC x 5/8 in	
62 LOHS057 (10) H557		Screw for 7 6-32 UNC x 5/8 in	
63 M14P008 (10)		Screw for 6 6-32 UNC x 5/16 in	
68 LOCT072 (10) C172		Screw for 11 8-32 UNC x 1/4 in	
69 L001030 (10) 0730		Nut for 60 4-40 UNC	
70 LOOT005 (10) 015		Nut for 61 6-32 UNC	
76 M14P009 (4)		Nut for 63 8-32 UNC	
77 M14P010 (4)		Bush for 3 and 4	
78 M14P011 (4)		Bush for 4	
79 LOHW315 (4) HW315		Bush for 4	
81 M14W022 (10)		Grommet for 3 and 4	
82 LOHW023 (10) HW23		Pin for 13	
83 LOHW025 (10) HW25		Terminal for 13	
84 M14W016 (10)		Boot for 13	
85 M14W025 (10)		Eyelet for 13	
86 LOHW104 (10) HW104		Sleeve for 13	
		Tie for 13	



Index No.	Part No.	cgual to	Part	Serial No.
1	F140066	10855/1	Bracket for 7	
2	F14B067	10855/13	Screw for 1	5/16 in BSF x 1 in
3	F14B068	10855/14	Washer for 3	
4	F140069	10855/15	Nut for 2	5/16 in BSF
5	F14B070	10855/7	Bracket for 7	
6	F148071	10855/16	Screw for 1	1/4 in x 1/8 in and 5
7	F140072	4903/1/0	Pillar for 1 and 5	
8	F14B073	6366	Nozzle for 10	
9	F140074	5523	Nozzle (wide angle) for 10	
10	F140075	6839	Telescopic Arm - complete	
11	F140076	8225	Plastic Hose	
12	F14B077	12703	Spray Gun - complete (not shown)	
13	F148078	12703/1	Top Cover for 12	
14	F14B079	12703/19	Spray Gun Bowl	
15	F140080	11259/2	Body for 17	
16	F140081	4542	Washer for 15	
17	F14B082	11259/4	Intake Connector	
18	F140083	10027/38	Washer for 17	
19	F140084	12639/14	Dial	
20	F14B062	9037	Spring for 24	
21	F140086	12703/16	Knob for 24	
22	F140087	12703/13	Air Tube Assembly	
23	F1413088	12703/2	Sealing Ring for 13	
24	F148089	12703/12	Valve Spindle	
25	F140090	12703/11	Bush for 24	
26	F14B091	12703/8	Stud Nipple for 22	
27	F140092	6285	Knurled Nut for 14	
28	F14B093	12703/3	Outlet Connector for 13	
29	F148094	12738	Screw for 30	2 BA x 1/4 in
30	F14B095	6363	Plug Assembly for 13	




4



15



19



21



56




55



57




30



52



51



31



57



32



61




14



60

Index No.	Part No.	Equal to	Part	Serial No.
1	EIOU005		Anti-Set-Off Spray 220/240V 50 Hz (not shown)	
2	EIOU006		Anti-Set-Off Spray 115V 60 Hz (not shown)	
3	EIOU007		Anti-Set-Off Spray 110V 50 Hz (not shown)	
4	F14B048	15001	Compressor - complete (state voltage and frequency when ordering)	
5	F146049	15001/2	Pump End Plate	
6	F146050	15001/1	Screw	
7	F14B051	15002	Vane	
8	F14B052	15005	Inlet Filter	
9	F14B053	15005/1	Lock Nut	
10	F148054	15005/2 --	Washer	
11	F148055	15005/3	Rubber Washer	
12	F14B056	15005/4	Filter Cover	
13	F14B057	15006	Capacitor	
14	F14E026		Plug for 4	
60	M14W022 (10)		Pin for 4	
Air Control Valve				
15	F148058	10855/17	Air Control Valve complete	
16	F14B059	10876/22	Nut for 15	
17	F14B060	10876/2	End Cap for 15	
18	F14B061	10876/4	Valve Seal for 15	
19	F146062	9037	Spring for 18	
20	F14B063	11753/1	Piston for 15	
21	F14B064	10855/8	Bracket for 15	
22	F14B065	1976	Lock Nut for 21	
50	LOC153 (10)	CRI53,OR21	Washer for 55	
55	L005352 (10)	C5352	Screw for 21	10-24 UNF X 3/8 in
Microswitch				
30	F14B045	3650	Microswitch	
31	E103015	3640	Bracket for 1	
32	F14B046	1025WT	Toggle Switch	
51	LOC1064 (10)	CR64,CRI54	Washer for 56	
52	L00R153 (10)	OR21,CRI53	Washer for 57	
56	LOC5418 (25)	CS418	Screw for 1	6-32 UNC x 1 in
57	L005009 (25)	OS9	Screw for 2	10-32 UNF x 1/2 in
61	LOCW778 (5)	CW778	Spring Peg for Item 5-D1	




=05

7

55


451 1




64

50

Index No.	Part No.	Equal to	Part	Serial N
1	E108037		Ink :oller Cleaning Attachment - complete with 1-8,50,55-58 and 63 (not shown)	
2	F14B096	602V-3	Trough	
1	F148097	610V-3	Cleaning Blade	
4	F148098	611V-3	Clamp Strip	
5	E10B038		Clamp Bar	
6	E10B024	91013024F99	Operating Lever - L.H.	
7	E10B022	901B022P99	Operating Lever - R.H.	
8	F14B099	609V	Squeegee Bottle	
50	M143016 (4)	211870016P	Washer for 55	
51	M14B002 (10)		Washer for 58	
55	PIOB010 (4)	910B010029	Screw for 6 and 7	
56	L00S036 (10)	0S36	Screw for 2 1/4 in-20 UNC x 1 in	
57	M14B001 (10)		Screw for 56 2 BA x 5/16 in	
58	L005368 (10)	C5368	Screw for 2 and 5	
63	L0CW562 (10)	CW562	Stop Pin for 6 and 7	




Index No.	Part No.	Equal to	Part	Serial No.
1	E14E173		4 Sucker System - complete with 2-13	
2	F14G014	20G	Sucker - L.H.	
3	F14G015	21G	Sucker - R.H.	
4	E14E143		Removable Holder for 2 and 3	
5	[14E158		Screw for 4	
6	E14E130	229G	Sucker for 2 and 3	
8	F14H002	2H	Air Pipe Connector for Vacuum Manifold Shaft	
9	F14H301		Y-Hose Connector	
10	E14E154		First Outer Sucker Hose	
11	E14E155		Second Outer Sucker Hose	
12	E14E156		Distributor Sucker Hose	
13	F14H305		Syphon Tap 1/4 in	
50	P14E157	(5)	Pin for 4	




Index No.	Part No.	Equal to	Part
1	E10H017		Blanket Cleaning Attachment (not shown)
2	E10H012		Trough
3	E10F039	910F039Y99	Hose
4	E05E253		Label
5	F14N308	624N-3	Cleaning Roller - 'Sponge
6	E10F078	625N	Hub - L.H. for 5
7	F14N311	626N-3	Hub - R.H. for 5
8	E10F060	630N	Sprocket for 5
9	F14N309	641N-3	Shaft for 5
10	F14N310	634N-3	Wiper Roller - complete with 62 and 87
11	F14N021	682N	Chain (39 links) for 8
12	F148099	609V	Bottle for 2
13	F14N036	603N	Tube for 2

St414d No



Indc x No.	Part No.	Equal to	Part	Serial ;to.
50	LOCR039 (25)	CR39	Shirr. +Jasher 25/64 in I.D. x 5/8 in O.O.	
52	LOHR049 (10)	HR49	Wave Washer for 17	
54	LOCR009 (10)	CR9	Washer for 68	
55	LOCR128 (25)	CR128	Lock Washer for 67	
56	LOCR134 (25)	CR134	Spring Washer for 68	
58	L00S018 (25)	0S18	Screw for 1 10-24 UNC x 7/8 in	
59	M14N003 (10)		Screw for 1 1/4 in-20 UNC x 3/4 in	
60	L05C362 (10)	CS362	Screw for 83 5/16 in-18 UNC x 1/2 in	
61	L0CS379 (10)	CS379	Screw for 80 8-32 UNC x 5/16 in and 82	
62	LOCS380 (10)	CS380	Screw for 87 6-32 UNC x 5/16 in	
63	LOCS400 (2)	CS400	Adjusting Screw for 1	
66	L00S386 (10)	CS386	Screw for 81 10-32 UNC x 1/8 in	
67	LOCS361 (10)	CS361	Screw for 1 1/2 in-20 UNC x 5/8 in	
68	L00S035 (10)	0S35	Screw for 1 1/4 in-20 UNC x 7/8 in	
72	LOOT008 (25)	OT8	Nut for 59 1/4 in-20 UNC	
76	LOCW405 (25)	CW405	Spring Dowel 1/8 in dia. x 3/4 in for 80	
77	L0CW445 (25)	CW445	Spring Dowel 1/8 in dia. x 1/4 in for 80 and 82	
78	LOCW705 (5)	CW705	Bearing for 79	
79	LOCW706 (5)	CW706	Pivot Stud	
80	LOCW710 (5)	CW710	Side Plate - L.H.	
81	LOCW711 (5)	CW711	Locking Collar for 63	
82	LOCW712 (5)	CW712	Side Plate - R.H.	
83	LOCW714 (5)	CW714	Stud for 8	
84	LOCW716 (4)	CW716	Spacer for 5	
85	LOHW039 (5)	HW39	Bearing for 8	
86	L0CW726 (5)	CW726	Bearing for 6 and 7	
87	L00W182 (10)	0W182	Bearing for 10	
88	LOCW834 (5)	CW834	Spacer for 9	
89	LOHW057 (50)	HW57	Nylon Plug for 81	
90	LOCW704 (5)	CW704	Link for 11	
93	LOCW718 (5)	CW718	Clip for 3	
94	LOCW719 (25)	CW719	Rivet for 93	

F?



BLANKET CLEANING ATTACHMENTS

E3


Index Part
No. No.

Equal to

Part

Serial Nu


1	E10H015		Operating Shaft
2	F14N022	656N	Operating Arm
3	F14N023	660N	Operating Plate
4	F14N024	664N	Connecting Link for 3 and 8
5	F14N025	666N	Drive Sprocket
6	F14N026	667N	Spindle for 5
7	F14N027	669N	Clutch Cam Sprocket
8	F14N028		Operating Arm
9	F14N029	679N	Idler Sprocket - complete with 98
11	F14N030	683N	Chain (63 Links)
12	F14N031	685N	Chain Guard
13	E14R195		Solenoid 23/25V 50/60 Hz
14	E10F100		Stop for 13
15	E10F097		Link for 13
16	E10F099		Arm for 1 and 15
19	E14A065		Blanking Disc




BLANKET CLEANING ATTACHMENTS

E4

Index Part No.	Equal to	Part	Serial No.
50	LOCP002 (25)	CP2	Spring Clip for 91,93 and 95
51	LOCP009 (25)	CP9	Spring Clip for 15,56 and 100
56	LOCR 121 (10)	CR121	Washer for 2
57	LOCR122 (10)	CR122	Packing Washer for 5
58	M14N009 (10)		Thrust Washer for 7
59	LOCR125 (10)	CR125	Washer for 97
60	LO2A086 (10)		Washer for 78
61	LOCR 147 (10)	CR147	Washer for 2 and 3
62	LOCR 153 (10)	CR153,OR21	Washer for 65
65	LOOS009 (25)	OS9	Screw for 13 10-32 UNF x 1/2 in
66	LOOS008 (25)	OS8	Screw for 6 10-32 UNF x 3/8 in and 97
68	M14N006 (10)		Screw for 16 10-32 UNF x 5/16 in and 99
69	M14N002 (25)		Screw for 2 10-32 UNF x 1/4 in and 94
70	LOCS363 (10)	C5363	Screw for 12 10-24 UNC x 1/2 in
79	LOCT072 (10)	C172	Nut for 19 4-40 UNC
83	LOCU237 (5)	CU237	Spring for 6
84	L04A141 (10)		Spring for 13
89	L03S223 (5)		Peg for 13
90	LOCW 444 (25)	CW444	Spring Dowel 3/32 in die. x 7/8 in for 2 and 16
91	LOCW703 (10)	CW703	Link Pin for 4 and
92	LOCW 704 (5)	CW704	Connecting Link for 11
93	LOCW708 (10)	CW708	Link Pin for 3 and 4
94	LOCW 709 (5)	CW709	Collar for 3
95	LOCW 715 (10)	CW715	Stud for 9
96	LOCW 717 (5)	CW717	Bearing for 7
97	LOCW 720 (5)	CW720	Clutch Cam Plate
98	LOCW 725 (10)	CW725	Bearing for 9
99	LOCW 724 (4)	CW724	Eccentric for 1
100	L03W079 (2)		Spring Peg for 84
101	M143017 (10)	231110536P	Bearing for 1 and R.H. Printer Side Frame



Index No.	Part No.	Equal to	Part	Serial
1	E10M031		Manual Plate Loader Platform - complete (not shown)	
2	E14N233		Printer Guard Upper - complete with 57, 62 and 69	
3	E14N235		Printer Guard Lower - complete with 4,56,57,63,64 and 70	
4	E14N059		Pivot Plate for 3	
5	E14N227		Plate Support	
6	E14N228		Bracket for 5 and 7	
7	E14N232		Platform	
8	E14N230		Bracket for 9	
9	E14N226		Shaft for 10	
10	E14N231		Plate Guide	
50	LOLP003 (25)	LP3	Spring Clip for 71	
51	LOLP004 (25)	LP4	Spring Clip for 9	
55	LOCR058 (25)	CR58	Washer (Nylon) for 71	
56	LOCR145 (25)	CR145	Washer for 63	
57	LOCR017 (25)	CR17	Washer for 62 and 64	
62	M14A012 (10)		Screw for 69 M5 x 12mm	
63	LOCS419 (25)	C5419	Screw for 4 6-32 UNC x 1/4 in	
64	LOOS013 (10)	OS13	Screw for 3 10-32 UNF x 1 in	
69	P14N202 (4)		Knob for 2	
70	L02N125 (5)		Bush for 3	
71	L035267 (10)		Stud for 5 and 6	
72	M14A013 (10)	211761056P	Rivet for 3 and 6 7.5mm	
73	M148003 (10)		Stop Rivet for 5 6.5mm	
74	M148004 (10)		Rivet for 6,7 and 8 8.5mm	



100

O

62

7

55



_50

2

63

76



0 4

00

3

64

4-

5

C9

a

5

-57

7(

Index No.	Part No.	Equal to	Part	Serial No.
1	F14B339	517P	Cylinder Check Lever	
2	F148340	521P	Latch for 1	
3	E14B109		Gear Guard	
4	E14R206		Plate for 5	
5	F14A010		Microswitch	
50	LOCP002 (25)	CP2	Spring Clip for 62	
55	LOCR005 (25)	CR5	Washer for 70	
56	L0LR022 (10)	LR22	Washer for 69	
57	L0LR008 (25)	LR8	Washer for 71	
62	LOHS200 (2)	HS200	Pivot Screw for 1	
63	L0CS392 (10)	C5392	Screw for 2	
64	LOCS341 (10)	C5341	Screw for 3	10-24 UNC x 1.1/4 in
69	M14M008 (10)		Nut for 4	8-32 UNC
70	LOCT060 (25)	CT60	Nut for 62	1/4-28 UNF
71	LOCT072. (10)	CT72	Nut for 5	4-40 UNC
76	LOCU013 (10)	CU13	Spring for 1 and 2	

