



Replacement parts for: DAVIDSON 221, 233, 241, 400, 500, 500P, 501 502P, 560, 600,

		PART #			PART #
	FILTER SPRING	P-12034		ELEVATOR HANDLE ASSEMBLY Feeder	P-50955
	TOGGLE SWITCHES Main drive Pump & Drive 500P, 700P	P-4869 P-15305		ELEVATOR HANDLE ASSEMBLY Stacker	P-502630
	UPPER PULLOUT ROLL	P-51125		ELEVATOR HANDLE SHAFT	P-50962
	DETECTOR Sheet feed	D-88-2057-01		(A) GUIDE Back stop	D-88-1333-01
	SUCTION FOOT	D-88-2827-01		(B) GUIDE L.H. Operators side	D-88-1331-02
	RUBBER SUCTION FOOT ASSEMBLY <i>For heavy stock</i> Complete 1) Holder 1) Sucker foot 1) Screw	D-88-2200-18 P-50168 P-5204 P-50067		(C) GUIDE R.H. Non-operators side	D-88-1331-03
	FEEDER GEARS, PAWLS & SPRINGS Drive gear Ratchet Feed & stop pawl Feed pawl spring Stop pawl spring	P-50452 D-88-1442-01 P-52786 P-52718 P-52787		STOP FINGER SHAFT ASSEMBLY Complete 500 Complete 700 Shaft with fingers only 500 Shaft with fingers only 700 Timing pulley for both Pin	D-88-5996-03 D-88-5996-04 D-88-6954-01 D-88-6954-02 D-88-1372-01 P-441
	TIMING BELTS Large (feeder) Small (conveyor)	P-1662 P-1656		STRAP ASSEMBLY (7" long strap) Complete (A) Block (B) Knob (C) Screw (D) Washer (E) Strap Strap (feeder)	D-88-4562-01 D-88-2167-01 P-312 P-35 P-561 D-88-4418-01 P-50420
	KNOB ASSY. Beater bar 500, 600, 700, 500P, 700P 3-5/8" KNOB ASSY. Beater bar 501, 601, 701, 502P, 702P 4-1/2"	P-50541 P-51819		STRAP ASSEMBLY (8-5/8" long strap) Complete (A) Block (B) Knob (C) Screw (D) Washer (E) Strap	D-88-2170-01 D-88-2167-01 P-312 P-35 P-561 D-88-2166-01
	UPPER FEED ROLL	D-88-1719-02 or C-310-007567D		MARBLE RETAINER 500 (12-1/2" long) MARBLE RETAINER 700 (19-1/2" long) MARBLE RETAINER 901 (21-1/2" long) MARBLE - 1" Glass MARBLE - 1" Steel	D-88-1760-01 D-88-1760-03 D-88-1760-04 P-761 P-759
	BEARING	P-767		CHANNEL ASSEMBLY (A) Rod (B) Nylon ball (C) Clip (D) Screw (E) Guide	D-88-2076-01 D-88-2186-01 P-752 D-88-3959-01 P-140 D-88-2077-01
	SHEET SEPARATOR or Cat whisker Brass	P-50114			
	STOP PAWL SPRING	P-52660			
	FEEDER RELEASE PAWL	P-52786			


THIS IS JUST A SAMPLE OF OUR TOTAL INVENTORY



601, 660, 700, 700P, 701, 702P, 760, 901, Dual-a-matic, Mark-I, Roll Converter

PART #		PART #	
	COUNTER ASSEMBLY		BLANKET CYLINDER GEAR
	500, 600, 700		Gear with keys D-88-1608-01
	702P		Gear only D-88-1610-01
	221, 233		Keys D-251-0088
	Counter arm		Screws P-1892
			
SPRINGS For jogger assembly		BLANKET DRUM GEAR COUPLING	
Operators side L.H. D-88-2188-01		500, 600, 700 D-88-1615-01	
Non-operators side R.H. D-88-2188-02		502P, 702P D-88-1615-02	
		221, 251, 233 Top plate cylinder coupling	
		D-251-0105	
		500P, 700P D-88-4377-01	
			
STRAP ASSEMBLY	D-88-3173-01	PLATE SEGMENT CLAMP	D-88-2597-01
		Screw	or D-88-2597-02
			P-57
			
CONVEYOR TAPE		STUD For blanket drum latch	
500, 501, 502P, 600, 700, 701, 702P		D-88-1635-01	
P-4990			
CONVEYOR TAPE			
221, 241			
P-3914			
CONVEYOR TAPE			
Roll Converter			
P-3913			
			
SPROCKET ASSEMBLY For conveyor		DACRON, NYLON & ALUMINUM GEARS	
P-8612		500, 600, 700 Off large cylinder gear	
		NYLON	
		D-88-1499-01	
		or D-88-3083-02	
		ALUMINUM	
		D-88-1499-X1	
		501, 601, 701 Off large cylinder gear	
		DACRON	
		C-306-009847D	
		500, 600, 700 Off ink unit	
		NYLON	
		D-88-1552-01	
		ALUMINUM	
		D-88-1552-X1	
		501, 601, 701, Off ink unit	
		DACRON	
		D-88-6720-01	
			
DACRON GEAR For blanket drum gear drive		GEAR For ink vibrator roll	
D-88-1396-03		501, 601, 701	
		C-120-004904D	
			
UNIVERSAL DRIVE SHAFT		CHROME DRAW SHEETS	
500 (for ball bearing or bushing)		500 - 13" (no bend)	
		D-88-2321-01	
		500 - 14" (with bend)	
		D-88-2321-02	
		600 - 11" (no bend)	
		D-88-2321-09	
		700 - 13" (no bend)	
		D-88-2321-05	
		700 - 14" (with bend)	
		P-30788	
		901 - 14" (with bend)	
		C-199-006704D	
			
MAIN DRIVE GEAR For drive shaft (Nylon or (S)teel		PACKING SHEETS	
500, 600, 700 Dualith		500, 501(.005) - 13"	
		D-221-0415	
		D-221-0416	
		D-221-0417	
		D-227-0006	
		D-227-0007	
		D-227-0008	
		D-233-0048	
		D-233-0049	
		D-233-0050	
		D-233-0189	
		D-233-0190	
		D-233-0191	
		C-199-006635D	
		C-199-006634D	
			
BLANKET HUB ASSEMBLY		PIN BAR For plate & impression segment	
Reinforced lip for durability & longer life.		500, 600, 700	
D-88-3928-01		C-125-007223D	

... The nylon gear is double wide & designed to preserve the life of your other gears. Just turn it around and reuse it. Twice the life span as original design and your machine will run up to 50% quieter.

Replacement parts for: DAVIDSON 221, 233, 241, 400, 500, 500P, 501 502P, 560, 600,

PART #	
	
EXTENSION BAR For impression segment 700, 601, 701, 700P	D-88-2822-03
	
DUCTOR ROLLER CLIP Ink & water	D-88-0804-01
	
DUCTOR SPRING LATCH For roller bracket Ink & water	D-88-2606-01
	
WASH UP BLADES For Baldwin wash up units 500, 501 (11-3/4 x 2-1/4, 4 Holes, Steel & rubber) D-88-5200-02 700, 701 (18-3/4 x 2-1/4, 5 Holes, Steel & rubber) D-88-5200-01 901 (20-3/4 x 2-1/4, 6 Holes, Steel & rubber) D-88-5200-03 NOTE: WASH UP UNITS ALSO AVAILABLE	
	
INK FOUNTAIN BLADE 500, 501, 502P D-88-1574-01 600, 601, 700, 701, 702P D-88-1574-03 901 D-88-1574-04	
	
FROG ASSEMBLY For dampening system 501, 601, 701 Complete D-88-6656-01 (A) Wiper D-88-6607-01 (B) Screw P-1871 (C) Lock washer P-644 (D) Frog D-88-6606-01 (E) Thumb screw P-312	
	
SMALL PNEUMATIC CYLINDER For jogger blower manifold	D-88-1857-01
	
STRIPPER PLATE For chain delivery section 600, 601, 700, 701, 702P	D-88-2649-02
	
GEARED DAMPENING ROLLER 500 Complete D-88-1469-07 501 Complete D-88-1469-09 700 Complete D-88-1469-08 Roller and shaft only 500, 501 D-88-1468-05 Roller and shaft only 700 D-88-1468-06 Gear 500, 700 D-88-1462-01 Gear 501 D-88-6724-01 Screw for all P-50	

PART #	
	
RUBBER STOP For Roll Converter paper stop assy. D-33-0504-01	
	
JOGGER PLATE ASSEMBLIES 500, 600, 700 (Non-operators side) D-88-1916-02 (Operators side) D-88-1915-02 (Rear) D-88-1913-04 or D-88-1893-01 501, 601, 701 (Rear) D-88-1893-03	
	
PAWL ASSEMBLY For pile jogger assy.	D-88-1863-02
	
CONTROL HANDLE ASSEMBLY (A) 500P, 700P (not shown) D-88-5363-01 (B) 501, 502P, 701, 702P D-88-5363-03 (C) 500, 700 D-88-1451-01 (D) 501, 601, 701 D-88-5363-02	
	
CONNECTING LINK ASSEMBLY (L.H. & R.H.) 500, 600, 700 D-88-4148-01 501, 601, 701, 702P P-8744	
	
OLD STYLE CONNECTING LINK Only (A) D-88-2817-01	
	
GRIPPER BAR LINK Only 500, 600, 700 (B) Operators side L.H. D-88-2533-01 (B) Non-operators side R.H. D-88-2818-01	
	
GRIPPER BAR CARR. LINK Only 501, 601, 701, 502P, 702P (B) Operators side L.H. P-8722 (B) Non-operators side R.H. P-8721	
	
GRIPPER BAR LINK Only 901 (B) Operators side L.H. C-399-006720D (B) Non-operators side R.H. C-399-006719D	
	
NEW STYLE CONNECTING LINK Only (A) P-8749	
	
JOGGER SPRING & BLOCK ASSEMBLY - Conveyor Complete D-88-2178-02 (A) Block only D-88-1968-01 (B) Thumb screw P-312 (C) Screw P-194 (D) Lockwasher P-623 (E) Spring - Left hand D-88-2188-02 (F) Spring stop D-88-2187-02 (G) Clip D-88-2286-01 (H) Spring - Right hand D-88-2188-01	

THIS IS JUST A SAMPLE OF OUR TOTAL INVENTORY

601, 660, 700, 700P, 701, 702P, 760, 901, Dual-a-matic, Mark-I, Roll Converter

PART



REPAIR KITS FOR ALL DAVIDSONS


... ELIMINATE COSTLY DOWN TIME WITH YOUR OWN EMERGENCY KIT FOR YOUR MODEL PRESS.

Master kit	P-1771 - 1053 pcs.
Nut kit	P-1769 - 87 pcs.
Washer kit	P-1770 - 79 pcs.
Screw kit	P-1766 - 447 pcs.
Ring kit	P-1767 - 105 pcs.
Pin kit	P-1768 - 234 pcs.
Spring kit	P-30327 - 101 pcs.



GRIPPER CHAINS (set of 2 only)

221, 251, 500, 700	P-8929
501, 601, 701, 502P, 702P, 901	P-8935



SAVE MONEY BY REPLACING ONLY THE PARTS THAT WEAR INSTEAD OF REPLACING THE WHOLE GRIPPER BAR ASSEMBLY.

GRIPPER BAR REPAIR KIT - 500, 501, 502 P-30739

Consists of:
(C) Gripper finger-qty. 4,
(D) Spring-qty. 4,
(E) Cam-qty. 1,
(F) Ret. ring-qty. 1,
(G) Spiral pin-qty. 8,
(H) Ret. ring-qty. 1,
(I) Cam roller-qty. 1,
(J) Ret. ring-qty. 1.

GRIPPER BAR REPAIR KIT - 700, 701, 702 P-30740


Consists of:
(C) Gripper finger-qty. 8,
(D) Spring-qty. 8,
(E) Cam-qty. 1,
(F) Ret. ring-qty. 1,
(G) Spiral pin-qty. 8,
(H) Ret. ring-qty. 1,
(I) Cam roller-qty. 1,
(J) Ret. ring-qty. 1.

GRIPPER BAR REPAIR KIT - 901 P-30744

Consists of:
(C) Gripper finger-qty. 8,
(D) Spring-qty. 8,
(E) Cam-qty. 1,
(F) Ret. ring-qty. 1,
(G) Spiral pin-qty. 8,
(H) Ret. ring-qty. 1,
(I) Cam roller-qty. 1,
(J) Ret. ring-qty. 1.

NOTE: REFERENCE ALL KEY NUMBERS ON THESE THREE REPAIR KITS TO GRIPPER BAR ASSEMBLIES IN THE NEXT COLUMN.

PART



GRIPPER BAR ASSEMBLY

... MADE OF REINFORCED STEEL TO PREVENT BOWING.
... UNIVERSAL - MAY BE USED FOR STANDARD OR SLITTER.

500	Complete (slitter not avail.)	D-88-2832-14
	(A) Anvil (standard)	D-88-6945-01
	(B) Shaft	D-88-6385-02
	(C) Finger	D-88-2518-01
	(D) Spring	C-199-006219D
	(E) Cam roller	P-1445
	(F) C-Ring	P-668
	(G) Spiral pin	P-345
	(H) C-Ring	P-682
	(I) Cam roller	P-1407
	(J) Retaining ring	P-700

501, 502P	Complete (slitter not avail.)	D-88-2832-15
	(A) Anvil (standard)	D-88-6945-02
	(B) Shaft	D-88-6385-02
	(C) Finger	D-88-2518-01
	(D) Spring	C-199-006219D
	(E) Cam roller	P-1445
	(F) C-Ring	P-668
	(G) Spiral pin	P-345
	(H) C-Ring	P-682
	(I) Cam roller	P-1407
	(J) Retaining ring	P-700

700	Universal - fits standard or slitter	
	Complete	p-700990
	(A) Anvil (slitter)	D-88-8037-01
	(B) Shaft	D-88-6385-04
	(C) Finger	D-88-2518-01
	(D) Spring	C-199-006219D
	(E) Cam roller	P-1445
	(F) C-Ring	P-668
	(G) Spiral pin	P-345
	(H) C-Ring	P-682
	(I) Cam roller	P-1407
	(J) Retaining ring	P-700

600, 700P 701, 702P	Universal - fits standard or slitter	
	Complete	D-88-2832-12
	(A) Anvil (slitter)	D-88-8037-02
	(B) Shaft	D-88-6385-04
	(C) Finger	D-88-2518-01
	(D) Spring	C-199-006219D
	(E) Cam roller	P-1445
	(F) C-Ring	P-668
	(G) Spiral pin	P-345
	(H) C-Ring	P-682
	(I) Cam roller	P-1407
	(J) Retaining ring	P-700

901	Complete (slitter not avail.)	C-399-006713D
	(A) Anvil (standard)	C-125-006722D
	(B) Shaft	C-311-006714D
	(C) Finger	C-117-006727D
	(D) Spring	C-139-006747D
	(E) Cam roller	P-1445
	(F) C-Ring	P-668
	(G) Spiral pin	P-3045
	(H) C-Ring	P-667
	(I) Cam roller	P-1407
	(J) Retaining ring	P-700