# **TECHNICAL BULLETIN**

NO: #30

DATE: MARCH 1991

TO:

**All Kompac Dealers** 

SUBJECT: Maintaining The Kompac-T

Proper cleaning of the rollers is essential to prolonging the printing life of the Kompac-T. It is recommended that you, as a Kompac Dealer, stress the following steps to your customers.

# DAILY WASHUP PROCEDURES

Remove the pan from the Kompac-T and drain all fountain solution. Reinstall pan on Kompac-T and place a cleanup mat on the plate cylinder. Apply a small amount of Varn Wash V-120 or VWM roller and blanket wash directly on the metering roller. When cleanup mat becomes ink covered, replace with a clean one and continue this process until mat remains clean.

NOTE: Do not leave ink in the Kompac-T overnight.

# **WEEKLY**

- 1. Apply Varn Revitol or OverNite roller detergent to the metering roller. Allow to run for 5 minutes. Then wash up the Kompac-T, using above procedures, until Kompac-T is thoroughly clean. Performed weekly, this routine will completely deglaze the Kompac-T and maintain a troublefree performance.
- 2. Flush the fountain bottle and dispensing valves with warm water.
- 3. Remove Kompac-T from color head. Remove any excessive ink buildup on frames, especially on the lower tie bar.

### MONTHLY

Check bolts in mounting brackets and cross frame screws, etc., for tightness.

# SEMIANNUALLY

it is recommended that you, as an Authorized Varn/Kompac Dealer Serviceman, remove the Kompac-T, disassemble and check all components for wear, replace worn parts, clean and check all pressures, and realign the Kompac-T on the press.

# WARNINGS

- Avoid using rubber rejuvenator in the Kompac-T during cleanup or maintenance procedures.
- 2. Do not use an ink knife or any other sharp instrument or any abrasive compound that could damage roller surfaces.

Revitalize your T-51 with Kompac-T...the printers edge when printing spot color, two color, or process color work.

Michael Pek Technical Representative Kompac Division